

# Power Hawk™ Series 700 Console Reference Manual

---



0830059-000

June 2001

## CAUTIONARY NOTICE

While the manufacturer has attempted to detail in this manual all areas of possible danger to personnel in conjunction with the use of this equipment, personnel should use caution when installing, checking out, operating and servicing this equipment, especially when power is on. As with all electronic equipment, care should be taken to avoid electrical shock in all circuits where substantial currents or voltages may be present either through design or short circuit. Caution should be observed in hoisting equipment, especially regarding large structures during installation.

The Manufacturer is specifically not liable for any damage or injury, arising out of a worker's failure to follow the instructions contained in this manual, or in his failure to exercise due care and caution in the installation, operation, checkout and service of this equipment.

## PROPRIETARY DATA

This document, the design contained herein, the detail and invention are considered proprietary to Concurrent Computer Corporation. As the property of Concurrent Computer Corporation it shall be used only for reference, contract or proposal work by this corporation, or for field repair of Concurrent products by Concurrent Computer Corporation service personnel, customers, or end users.

Copyright 2001 by Concurrent Computer Corporation. All rights reserved. This publication or any part thereof is intended for use with Concurrent products by Concurrent Computer Corporation personnel, customers, and end-users. It may not be reproduced in any form without the written permission of the publisher.

The information contained in this document is believed to be correct at the time of publication. It is subject to change without notice. Concurrent Computer Corporation makes no warranties, expressed or implied, concerning the information contained in this document.

To report an error or comment on a specific portion of the manual, photocopy the page in question and mark the correction or comment on the copy. Mail the copy (and any additional comments) to Concurrent Computer Corporation, 2881 Gateway Drive, Pompano Beach, FL 33069. Mark the envelope "**Attention: Publications Department.**" This publication may not be reproduced for any other reason in any form without written permission of the publisher.

Night Hawk, Power Hawk, PowerStack II and PowerMAX OS, are trademarks of Concurrent Computer Corporation  
Synergy, VGM5 and VSS4 are trademarks of Synergy Microsystems, Inc.  
UNIX is a registered trademark of the Open Group.

Printed in U. S. A.

Revision History:	Level:	Effective With:
Original Release June 2001	000	New Product Release of Series 700

# Preface

## Scope of Manual

This manual describes the console for Concurrent Computer Corporation's Power Hawk Series 700 system. This manual provides information on how to use the console to debug the system. Series 700 systems use the following single board computers (SBC) manufactured by Synergy Microsystems, Inc.

<b>Concurrent System Platform</b>	<b>Motherboard Type</b>	<b>Number of Processors</b>	<b>Form Factor</b>
Power Hawk 710	VGM5 -Single	1	VME 6U
Power Hawk 720	VGM5 - Dual	2	VME 6U
Power Hawk 740	VSS4 - Quad	4	VME 6U

## Structure of Manual

This manual consists of a title page, this preface, a master table of contents, three chapters, three local tables of contents for the chapters, two appendixes, and an index. A brief description of the chapters and appendixes follows:

- Chapter 1 explains where the console fits in a system and describes the hardware of the console.
- Chapter 2 describes what occurs during system initialization and the console interface.
- Chapter 3 contains an alphabetical listing of the console debugging commands. Each command listing contains the purpose of the command, its syntax, an explanation of the command parameters, and examples of the command syntax and usage.
- Appendix A is a quick reference guide that lists the console commands and their meanings, as well as an explanation of the command parameters.
- Appendix B lists the possible error codes that may appear executing console commands. There is also a short description of the error and a possible cure to the problem.

The index has an alphabetical list of all paragraph formats, character formats, cross reference formats, table formats, and variables.

## Syntax Notation

The following notation is used throughout this guide:

<i>italic</i>	Books, reference cards, and items that the user must specify appear in italic type. Special terms may also appear in italic.
<b>bold</b>	User input appears in bold type and must be entered exactly as shown. Names of directories, files, and commands also appear in bold type.
list	Operating system and program output such as prompts and messages and listings of files and programs appears in list type.
[ ]	Brackets enclose command options and arguments that are optional. You do not type the brackets if you choose to specify such option or arguments.

## Vendor Documentation

Synergy commercial off-the-shelf (COTS) documentation applicable to the various Synergy Single Board Computers (SBC), are listed below. You may contact your local Synergy sales office to purchase Synergy manuals not provided with the system. See the table below for a list of Synergy manual names and document numbers.

Manual Name	Synergy Document Number	VGM5 Single Processor SBC	VGM5 Dual Processor SBC	VSS4 Quad Processor SBC
VGM5 VMEbus Dual G3/G4 PowerPC Single Board Computer User Guide	98-0317/UG-VGM5-01	X	X	-
VSS4 Quad 750 PowerPC VMEbus Single Board Computer for DSP User Guide	99-0062/UG-VSS4-01	-	-	X
SMon PowerPC Series SBCs Developers Application & Debugger User Guide	99-0041/UG-PPSM-01	X	X	X

# Contents

## Chapter 1 Introduction to the Console

Overview of Console .....	1-1
---------------------------	-----

## Chapter 2 Startup

System Initialization .....	2-1
FDIAG Initialization .....	2-1
SMON Initialization .....	2-2
Console Initialization .....	2-4
System Boot .....	2-5
Console Interface .....	2-7
System Entry to Console .....	2-7
VGM5 Reset/SMI Toggle Switch .....	2-8
VSS4 Reset/SMI Toggle Switch .....	2-9

## Chapter 3 Console Debugging Commands

Summary of Commands .....	3-1
Syntax Conventions .....	3-2
Command Format .....	3-4
Command Specifier .....	3-5
Data Size and Format .....	3-5
Global Options .....	3-5
Local Options .....	3-6
Numeric Values .....	3-6
Address Value .....	3-6
Command Manipulators .....	3-7
Command Editing .....	3-9
Console Commands .....	3-10

## Appendix A Command Summary

## Appendix B Error Codes

## Illustrations

Figure 2-1. VGM5 Reset and SMI Toggle Switch .....	2-6
Figure 2-2. VSS4 Reset and SMI Toggle Switch .....	2-7

**Tables**

Table 3-1. Console Debugging Commands - Summary .....	3-2
Table 3-2. Console Special Key Functions .....	3-6
Table 3-3. Effect of pboot on Boot Process .....	3-22
Table 3-4. General-Purpose Registers .....	3-27
Table 3-5. Processor Registers Accessed via p Command .....	3-34
Table 3-6. y Command Flag Bits .....	3-59
Table A-1. Command Parameter Definitions .....	A-8

# Introduction to the Console



Overview of Console ..... 1-1





# Introduction to the Console

---

## Overview of Console

The console for the Power Hawk Series 700 system allows the operator to initialize the system and perform certain diagnostic procedures. An overview of this product is provided in the following paragraphs.

The Power Hawk Series 700 system normally begin execution in the **SMon** program that is located in flash memory. **SMon** will then autoboot the Power Hawk Series 700 system console off of the appropriate boot media. The console is provided in a 'loadable' format at the front of bootable media. The **SMon** internal ROM bootstrap code reads the console into memory, where it then relocates itself to higher memory locations and begins execution.

The exact mode of operation depends upon the operator action and NVRAM settings during the start-up. If the operator interrupts the boot sequence or has set up NVRAM setting to prevent the boot sequence from autostarting, a console prompt will be output and console commands may be used for debugging or system start-up as described later in this manual. If the boot is not interrupted, the system bootstrap is fully automatic and the PowerMAX OS kernel will be brought up to the multi-user system level specified in the `/etc/inittab` file.



# 2 Startup

---

System Initialization . . . . .	2-1
FDIAG Initialization. . . . .	2-1
SMON Initialization. . . . .	2-2
Console Initialization . . . . .	2-4
System Boot . . . . .	2-5
Console Interface . . . . .	2-7
System Entry to Console . . . . .	2-7
VGM5 Reset/SMI Toggle Switch. . . . .	2-8
VSS4 Reset/SMI Toggle Switch. . . . .	2-9



## System Initialization

System initialization can be separated into four distinct areas: FDiag Initialization, SMon Initialization, Console Initialization and System Boot. These occur as described in the following paragraphs. The screen examples shown below are typical. They may vary due to particular system settings and/or firmware versions.

### FDIAG Initialization

A Synergy board as shipped from the factory is likely on powerup to stop at the **FDiag** prompt. **FDiag** is a ROM-based program from which standalone board diagnostics can be executed. An example of a **FDIAG** boot sequence is shown below.

```
X: CPU 0 started - User switch = 0x00
X:
Y: CPU 1 waiting on console
X: Hard reset.
X:
X: Board: VGM5-D ECO: 4 Special Mod. : 0 Serial#: 0000080
X: Number of CPUs : 2 Bus Speed (MHz): 66
X: CPU Type : 750 Rev : 8201 Speed : 300MHz
X: L2 Cache Size : 1MB Clock Ratio : 1.5:1
X: Memory Bank Size : 32MB Number : 4
X: Memory Size : 128MB Type : SDRAM, CL=2, Registered
X:
X: Bus Idsel Vendor Device ID Rev Class Sub-Class Part Name
X: 0 0 1057 2 40 6 0 Motorola Grackle
X: 0 11 1014 46 0 FF 0 IBM MPIC
X: 0 12 1000 D 2 1 0 Symbios 885 SCSI
X: 0 12.1 1000 701 2 2 0 Symbios 885 Ethernet
X: 0 17 10E3 0 1 6 80 Tundra Universe II
X: 0 18 1011 46 1 6 80 DEC 21554 Bridge
X:
X: --- Synergy Diagnostics --- Rev: 5.1.6 Apr 28 2000 16:04:04
X:
X: Starting shell on cpu: 0
Type 'help' for help.
FDiag0>
```



A startup script is created using the **SMon** command **vi**:

**vi "startup"** (the name `startup' MUST be surrounded by double quotes.)

**SMon** provides a subset of the familiar **vi** editor commands to its users. Edit the script to reflect the following file contents, then type **:q** to save and exit (do not use **:w**).

**scsidiskboot 0** (replace the `0' with the SCSI ID of the PowerMAX OS boot disk you will be using).

Once the startup script is created, it's execution during **SMon** startup can be enabled. This is done using the **smonconfig** command:

SMon0> **smonconfig**

For each of the following questions, you may hit <return> to keep the value in braces, or you may enter a new value

The SMon ROM can be used in several ways:

- (1) ROM-boot SMon Stand-alone
  - (2) ROM-boot SMon with startup script
- Which one do you want? [1] **2**

HARDWARE PARAMETERS:

The slave address is the BASE + (INDEX \* SW[0-3])  
 Slave address on BUS? [0x20000000]  
 Slave address base of control registers on BUS? [0xD0000000]  
 BUS Offset INDEX for switch position? [0x00000000]  
 Slave address for BUS is 0x20000000  
 Slave address for control registers on BUS is 0xD0000000

TERMINAL SETTINGS

What baud rate should serial port A use? [9600]  
 What baud rate should serial port B use? [115200]  
 What port should be the console? [**A**]

How long (in seconds) should CPU delay before starting up?[0] **9**

ETHERNET PARAMETERS:

What should the board unique serial number be? [00:00:00] (**See Note Below**)  
 What should the ethernet host address be? [00.00.00.00]  
 What should the ethernet target address be? [00.00.00.00]  
 What should the ethernet mask address be? [00.00.00.00]  
 What should the ethernet gate address be? [00.00.00.00]

SMon0>

### Note:

Enter the second half of a unique Ethernet MAC address for this board (e.g., 00:05:80) if this board is to be connected to a network. (The **SMon** command **'rsn'** (read motherboard serial numbers) may be used to read/verify contents of this field.)

**The critical items in the above run are:**

The SMon ROM can be used in several ways:

- (1) ROM-boot SMon Stand-alone
- (2) ROM-boot SMon with startup script

Which one do you want? [1] 2

and

How long (in seconds) should CPU delay before starting up?[0] 9

In the first answer, we tell **SMon** we want it to run 'startup' at boot time. In the second answer, we tell **SMon** to wait 9 seconds before doing so.


## Console Initialization

### Note

The following assumes the PowerMAX OS has been previously installed. If the OS has not been installed on your system, please refer to the appropriate version of the *Power Hawk Series 700 PowerMAX OS Release Notes* (Pubs No. 0891084-x.x) for installation instructions.

When **SMon** loads what it thinks is the OS from the boot media, it is actually loading the PowerMAX OS Console software package described in this document. Console initialization consists of determining the console device and selection of debug or system boot modes. The console normally operates on an ASCII terminal connected to Serial Port A.

The PowerMAX OS Console startup sequence appears as follow:



SMon Rev: 5.1.6 Apr 28 2000 16:29:08  
Copyright (c) 1994-2000 Synergy Microsystems.

Synergy VGM5-D PowerPC 750 @ 300 MHz, 66 MHz bus, 128 MB DRAM.

```

-----
BOOT METHOD:      ROM-boot SMon with startup script.
HARDWARE PARAMETERS: Bus slave @ 0x20000000, regs @ 0xD0000000.
                  Bus index 134217728.
TERMINAL SETTINGS: Serial A baud: 9600, Serial B baud: 115200.
                  Console port: A. Start delay: 5 sec.
ETHERNET PARAMETERS: Hardware address: 00:80:f6:00:00:80.
                  Host: 00.00.00.00 Target: 00.00.00.00
                  Mask: 00.00.00.00 Gateway: 00.00.00.00.
-----

```





ETHERNET PARAMETERS: Hardware address: 00:80:f6:00:00:80.  
Host: 00.00.00.00 Target: 00.00.00.00  
Mask: 00.00.00.00 Gateway: 00.00.00.00.

-----  
To change any of this, hit any key ... 0  
Executing startup script  
scsi device id=2 READY!  
probing SCSI... 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14  
3 scsi device(s) found  
booting from disk Unit 1  
device block size is 0x200  
Boot Partition starts at 00000000 length 00000347 byte offset 00000000  
Load image length 00068E00 entry offset 00010000

PowerMAX\_OS Synergy Console (5.0-20000712)  
- Board VGM5-d, 128MB, 2 300MHz PPC-750s each with 1MB L2 Cache, 66MHz bus.  
- Board options: scsi YES ethernet YES p0-pci YES user burnable flash NO.  
- CPU 0 stats: chip major rev 2, minor rev 1, chipmaker Motorola.  
- Boot parms: fd -sw dsk(0,2,0,0), y0, p -sw boot 80, p about 5.  
CPUs 0 1 up.

Type `#` to cancel boot, `!` to boot immediately (9 seconds).....  
ncr0)0.2.4.....  
dsk(0,2,0,0)/.  
dsk(0,2,0,0)/stand/boot  
pboot 00000080  
PowerMAX OS Boot Loader  
Boot  
:/stand/unix  
2683832+297207+508045 start 0x4000  
symbol table loaded

Concurrent PowerMAX\_OS Release 5.0

Global Memory: 133935104 bytes

Initialize I/O level 0 interface: SYS.PCI0  
vp driver initialized  
ncr0: on SYS.PCI0  
sym0: on SYS.PCI0

The system is coming up. Please wait.

SCSI device @ID 0 on ncr adapter 0: disk  
SCSI device @ID 2 on ncr adapter 0: disk  
SCSI device @ID 4 on ncr adapter 0: cd-rom  
Checking root filesystem  
Node: zappa  
Checking /var filesystem

Checking file systems:

File system check complete.

UX:hrtcconfig: INFO: /dev/rrtc/0c0 configured as HRT callout queue RTC  
The system is ready.

The system's name is zappa.  
Welcome to Synergy PowerMAX\_OS Release 5.0  
Console Login:

The ‘Boot params:’ line in the above example gives real console commands that were executed for you when the console started up. They came from the area of NVRAM reserved for the console. See Chapter 3, Console Debugging Commands, for detailed description of these and all the other console commands.

## Console Interface

Unlike **SMon**, the console understands several PowerMAX OS filesystem types, and hence is able to reach into and load into memory whatever files the console user desires to be loaded (see the **fl**, **fr** and **fb** commands). However, the console understands only one file format - that of a raw, executable image. That is, it is able to load a file bit-for-bit into a default or designated memory location, and if to be executed, will jump to the load location of the file, in effect assuming that is the first instruction which is to be executed. If the desired file to be executed is not in this format, then a helper program that is in this format must first be loaded. One such program is provided with a PowerMAX OS installation: **/stand/boot**. This booter understands the **ELF(3E)** file format created by the PowerMAX OS **cc(1)** command. Since the PowerMAX OS kernel is in ELF format, **/stand/boot** must be used when loading and executing a PowerMAX OS kernel.

**/stand/boot** is loaded and executed automatically by the **fb** command. The **fb** command is identical to **fb** except that it allows the operator to specify a different **/stand/boot** file (assuming one exists). The **fl** command allows the operator to load a **/stand/boot**-like file but not automatically execute it. The **fc** command gives the operator **ls(1)**-like listings of directory contents on the root filesystem.

**/stand/boot** will automatically boot and execute **/stand/unix**, the actual PowerMAX OS kernel, unless it has been told to ask for an alternate filename to boot, via a **pboot** flags setting.

The console makes breakpoint, trace, and other debug services available once a PowerMAX OS kernel, or standalone program such as **/stand/boot**, has started execution.

## System Entry to Console

Any entry from a program to the console is performed via exceptions. These exceptions consist of breakpoint, trace, halt, and error. Upon entry to the console, the current context, system and user registers, and operating modes are saved and the **#>** prompt is output. Commands described in Chapter 3 of this manual may then be input. Control is also transferred to the console if the operator enters the sequence ‘<CR>~i’ at the system console while the PowerMAX OS kernel is in operation.

Control may be returned to the executing program by entering the **r** (Run) command. Note that if File (**f**) commands are used, it is no longer possible to return to the operating system at the point it entered the console.

## VGM5 Reset/SMI Toggle Switch

The VGM5 motherboard has a RESET and SMI toggle switch for each CPU. See Figure 2-1.

<p><b>RESET</b></p>	<p>Assert either a <b>CPU</b> or board-level <b>RESET</b> as described below.</p> <p>Pushing a switch to the <b>right</b> asserts a CPU-level RESET to the corresponding CPU. The <b>CPU-X</b> (top) switch asserts a reset to the CPU on single CPU models and to <b>CPU-X</b> on the dual CPU models. The <b>CPU-Y</b> switch (bottom) asserts a reset to <b>CPU-Y</b> which has an effect only on dual CPU models.</p> <p>Pushing <b>both</b> switches to the right at the same time asserts a board-level reset on all VGM Series models:</p> <ul style="list-style-type: none"> <li>• Resets the CPU(s).</li> <li>• Resets all on-board components that have such a function and clears all on-board control registers.</li> <li>• Asserts a VME RESET if the board is serving as the System Controller.</li> </ul>
<p><b>SMI</b></p>	<p>Pushing a switch to the <b>left</b> asserts an SMI interrupt to the respective CPU.</p> <p>Pushing the bottom switch to the left has no effect on single processor boards.</p>




Figure 2-1. VGM5 Reset and SMI Toggle Switch

## VSS4 Reset/SMI Toggle Switch

The VSS4 motherboard is provided with a toggle switch for RESET and SMI interrupts. See Figure 2-2.

<b>RESET</b>	<p>Pushing a switch to the <b>right</b> asserts a board-level RESET which:</p> <ul style="list-style-type: none"> <li>• Resets the CPUs.</li> <li>• Resets all on-board components that have such a function and clears all on-board control registers.</li> <li>• Asserts a VME RESET if the board is serving as the System Controller.</li> </ul>
<b>SMI</b>	<p>Pushing the toggle switch to the <b>left</b> asserts an SMI interrupt to all CPUs on the board.</p>




Figure 2-2. VSS4 Reset and SMI Toggle Switch



# Console Debugging Commands

---

Summary of Commands .....	3-1
Syntax Conventions .....	3-2
Command Format .....	3-4
Command Specifier .....	3-5
Data Size and Format .....	3-5
Global Options .....	3-5
Local Options .....	3-6
Numeric Values .....	3-6
Address Value .....	3-6
Command Manipulators .....	3-7
Command Editing .....	3-9
Console Commands .....	3-10





## Console Debugging Commands

### Summary of Commands

A summary of the console command set is shown in Table 3-1. This command set not only supports booting, but also the debugging of standalone programs (including the PowerMAX OS kernel) through the use of breakpoint services and the ability to examine and change registers and memory locations on command.

When the console is ready for a new command, it will display one of several prompts:

#>

is displayed for uniprocessor systems.

#0>

is the most common display for multiprocessor systems. The numeric value (0) is the CPU the console is running on (called the master CPU), AND the CPU whose registers will be examined, modified, or stepped by default when no CPU is specified on the command line (the attentive CPU).

#0:1>

This prompt is display when the master CPU (0) is different from the attentive CPU (1).

By default the master CPU is always CPU 0. This can be changed with the **tm** (configure master CPU) command. Sometimes the CPU that is currently the master CPU will be changed automatically; this can occur for example, if the master CPU ceases to respond. The attentive CPU can be changed with either the **tm** or the **o** (global command options) command. When changing the master CPU, be aware that although the console runs fine with any CPU being the master, some booted programs (notably the PowerMAX OS kernel) will not run if booted with any other then CPU 0 being the master.

The console provides an online help facility through the **? command**. The various forms of help are:

- ? - a short help overview
- ?? - a more detailed help overview
- ?e - help on the 'e' command (substitute any other command name for 'e')
- ?- - help on the most common command line options
- ?\* - help on the command line editor

Finally, it is possible to exit the console and restart **SMon** by executing the **<CR>~b** command. This command performs a 'soft reset' of the system. Other commands are available that can reset a system by 'yanking' on the various 'hard reset' lines. For example, **<CR>~h** yanks on the VME bus reset line while **<CR>~p** yanks on the PCI bus reset line. When any of these lines are 'yanked', all devices that listen to a given line will undergo a hardware reset. These commands are unique from all others in that they must be preceded by a carriage return **<CR>** in order to be recognized. They can also be typed-in and acted upon by the console while console output is being generated.

## Syntax Conventions

The following conventions are used in the command syntaxes:

**<a>** – **a** is mandatory

**[a]** – **a** is optional

**a|b** – either **a** or **b** but not both. The **a** option or **b** option can be used with the command but the **a** option cannot be used along with the **b** option. Note that there may be a string of **OR** options (i.e., **a|b|c|d|e**) in this case you can only have one option, either **a** or **b** or **c** etc.

**Table 3-1. Console Debugging Commands - Summary**

Command	Definition	See Page No.
<b>a</b>	ASCII Dump	3-11
<b>b</b>	List Breakpoints	3-14
<b>b</b>	Set Breakpoints	3-15
<b>bk</b>	Clear Breakpoints	3-16
<b>c</b>	Copy Memory	3-17
<b>d</b>	Display Memory in Hexadecimal	3-19
<b>di</b>	Disassemble Memory	3-22
<b>e</b>	Examine/Change Memory	3-23
<b>fb</b>	Boot Operating System	3-25
<b>fc</b>	Display Directory	3-27
<b>fd</b>	Display/Set Default Device	3-28
<b>fh</b>	Display Mounted File Systems	3-30
<b>fl</b>	Load Program	3-31
<b>fr</b>	Load and Execute a Program	3-32
<b>g</b>	General Register Display/Modify	3-33
<b>i</b>	Initialize Memory to Value (Fill)	3-35
<b>k</b>	Kick CPUs	3-37
<b>m</b>	Memory Test	3-38
<b>o</b>	Global Command Options	3-39
<b>p</b>	Processor Register Display/Modify	3-40
<b>qa</b>	Query Address	3-43
<b>qb</b>	Query Backplane	3-44
<b>qp</b>	Display SPR register	3-45
<b>qs</b>	Query Stack	3-46
<b>qv</b>	Query Virtual Address	3-47
<b>qy</b>	Query Current Boot Options	3-48
<b>r</b>	Execute Run	3-49
<b>ra</b>	Execute Run to Address	3-50
<b>rd</b>	Run Without Breakpoints	3-51
<b>rn</b>	Run to Next Instruction	3-52
<b>rr</b>	Run to Return Address	3-53

**Table 3-1. Console Debugging Commands - Summary (Cont.)**

Command	Definition	See Page No.
<b>s</b>	Search Memory for Data	3-54
<b>sr</b>	Search Memory Range for Data	3-56
<b>td</b>	Configure CPU Down (multiprocessor SBCs only)	3-57
<b>tm</b>	Configure Master CPU	3-58
<b>tu</b>	Configure CPU Up (multiprocessor SBCs only)	3-59
<b>w</b>	Write Data to Memory	3-60
<b>y</b>	Initialize Boot Options/Flags	3-61
<b>z</b>	Single-Step Processor	3-62
<b>?</b>	Help Command	3-63

Some options are specified by a dash (-) followed by the option character. Command, options, and data must be entered in lower case. In this manual, parameters which must be entered are enclosed in < >. Optional parameters are enclosed in brackets [ ]. Optional parameters include such items as ending addresses for display commands. In general, the command syntax is shown below:


```

command -options start_address ending_address data
OR
command -options start_address:byte_count data
    
```

Most commands are terminated in one of two ways: by typing a period or by entering a carriage return <CR>. If a command is terminated via a period, the command executes immediately and then displays the prompt. If the command is terminated via a carriage return the command executes and then allows the use of one of the repeater commands. Repeater commands are discussed later in this chapter under the *Command Manipulators* heading.

## Command Format

Although there is no format common to all the commands described in this chapter, most of the commands have one or more of the features listed in the sample command shown below.



## Command Specifier

Table 3-1 briefly described each of the console debugging commands. These are the basic commands without their optional parameters.

## Data Size and Format

The range of values for formatted data:

- b** Formatted as a byte – transfers data via eight-bit transfers,
- w** Formatted as a word (two bytes) – transfers data via 16-bit transfers, or
- l** Formatted as longwords (four bytes) – transferred in a single 32-bit transfer. This is the default.
- r** Reverse byte order. Controls byte ordering of 16-bit or 32-bit number. If **r** is not specified, byte ordering begins with the highest order byte as Byte 0 (Big-Endian). If **r** is specified, byte ordering begins with the lowest order byte as Byte 0 (Little-Endian). If the '**r**' suffix is present, it must follow any '**b**', '**w**', or '**l**' suffix that is present.

The data formats described above are depicted in the console command syntax conventions illustrated in the following example.

```
e[format][-b<n>][-p|-n][start_address[data]]
```

Where **[format]** has the following syntax convention:

```
[b|w|l][r]
```

Therefore, for data formats you may specify at most one of **b** or **w** or **l** followed by an optional **r** to reverse the retrieval and storage of bytes by the command.

## Global Options

Some commands look at or can set various global options. See the '**o**' command on page 3-39 for more information on command options).

- b<n>** Specify program base address. The base address, represented by the address value *n*, is added to all addresses entered from the command line. The address value *n* is zero by default. Numeric address values are discussed later in this chapter.
- c<n>** Specify the attentive CPU<n> for this command.

## Local Options

The following 'local' options are commonly available on many commands.

- n<addr>** Address arguments are with respect to the NVRAM address space.
- p<addr>** Address arguments are with respect to the PCI configuration space.
- s** Store into NVRAM when appropriate.
- w** When storing into NVRAM, don't ask 'are you sure?'.

## Numeric Values

A numeric value may be entered in any of the following formats.

- 'cccc'** ASCII value.
- hex digits** Hexadecimal number.
- \$** Value of last entered address parameter.
- %** Contents of the program counter of the default processor.
- %regname** Contents of the specified processor register of the default processor.
- BnBnBn** Hex value of all the specified bits added together (e.g., **B2B0 = 5**).
- [\]symbol** Console or program symbol (operating system or diagnostic) name. Leading backslash required when a symbol doesn't contain a leading underscore (\_).

## Address Value

An address may be entered in any of the following formats.

- numeric value** Physical address by default. If the **o+v** option is set, and virtual memory is enabled then the address defaults to virtual; otherwise, the address is physical.
- [numeric value]** A physical address is specified by enclosing a numeric value within square brackets.

- (numeric value)** A virtual address is specified by enclosing a numeric value within parenthesis. The SDR0 and SDR1 registers for the processor contain the address of the translation tables.
- \*numeric value:size** An indirect address is specified by placing an asterisk (\*) before a numeric value. Note that specifying indirection is valid only for memory reference options. The optional size parameter specifies the size of the indirect memory reference and must be in the range 1 through 4.
- \*[numeric value]:size** Indirect physical address. The optional size parameter specifies the size of the indirect memory reference and it must be in the range 1 through 4.
- \*(numeric value):size** Indirect virtual address. The optional size parameter specifies the size of the indirect memory reference and it must be in the range 1 through 4.

## Command Manipulators

There are two categories of command manipulators: terminators and repeaters. Most commands can be terminated (exited) in one of two ways: by pressing the <CR> key or by typing a period (.).

If a command line is terminated by typing just a period, the command executes immediately and then the prompt is displayed, sometimes on the same line as the command results. Note that typing another period after the command has terminated causes that command to repeat.

If a command line is terminated by pressing the <CR> key, the command executes and then allows a repeat of the command (or a version of the command) via one of the following **repeaters**. (Note that not all repeaters are valid for all commands.).

- When a dash (-) is used as a repeater the current data is displayed in ascii and as binary bits (e.g. **B26 B5 B0**). Note that this repeater is only valid for the **e**, **g**, and **p** commands.

**<n><CR>** Change address to <n>.

**@** Keep same address.

**<SP>** Increment address to next page.

**<CR>** Increment address to next line.

**/** Decrement address to previous page.

**.** Repeat or exit current command.

Any command can be aborted by typing **CTRL-C**. This action causes a soft reset of the console. Any commands typed but not yet executed are ignored.

The following example shows the effect of the various command terminators.

```
#0>db 0:10<CR>
```

```
00000000 36 03 63 38 53 60 50 41 17 C0 FF EE D0 C0 02 37 ,  
00000010 73 20 0C 0D EE FF 0C 71 14 05 06 35 83 36 30 63 /  
  
00000000 36 03 63 38 53 60 50 41 17 C0 FF EE D0 C0 02 37 @  
00000000 36 03 63 38 53 60 50 41 17 C0 FF EE D0 C0 02 37 <SP>  
00000010 73 20 0C 0D EE FF 0C 71 14 05 06 35 83 36 30 63 <CR>  
00000020 45 33 07 01 00 AC DC FE 98 48 42 43 16 41 44 FF 70<CR>  
00000070 FF 44 14 61 34 24 84 89 EF CD CA 00 10 70 33 54 .  
#0>
```



## Command Editing

Table 3-2 lists the character sequences that you may enter to edit the commands discussed in this chapter.

**Table 3-2. Console Special Key Functions**

As an aid to the creation of command lines to be executed, the console remembers a number of previously executed command lines and provides their contents for viewing, editing, and possible re-execution. The command line editor functions and their invoking keystrokes are listed below:	
<b>CTRL-f, CTRL-b</b>	- move forward/backward one character
<b>CTRL-a, CTRL-e</b>	- move to beginning/end of line
<b>del, CTRL-d</b>	- delete character under the cursor
<b>CTRL-h</b>	- delete previous character
<b>CTRL-n</b>	- move forward to the next input line in the history buffer
<b>CTRL-p</b>	- move to the previous line in the history buffer
<b>CTRL-r, CTRL-l</b>	- re-display input line
<b>CTRL-k</b>	- delete to end of input line
<b>CTRL-u</b>	- delete entire input line
The console, at all the times it is actually running, monitors all keystrokes entered, looking for special ones that it is to act upon right away. The single-keystroke versions of these are:	
<b>CTRL-c</b>	- kill the currently running console command, return immediately back to the console prompt.
<b>CTRL-s</b>	- (XOFF) pause console output display
<b>CTRL-q</b>	- (XON) restart paused console output display
The console also monitors and acts upon the following keystroke triplets whenever they occur.	
<b>&lt;CR&gt;~b</b>	- soft reset of only this board.
<b>&lt;CR&gt;~p</b>	- hard reset of only this board (PCI bus reset)
<b>&lt;CR&gt;~h</b>	- hard reset of all boards in this rack (VME bus reset on 720 boards; watchdog timer reset on 740 boards)
<b>&lt;CR&gt;~o</b>	- hard reset of all boards in the rack <b>excluding</b> the board on which this command was executed. Available only to 720 boards which are the VMEbus master controller).
Finally, while not properly the subject of the console, PowerMAX OS watches for several console-like keystroke triplets while it is running:	
<b>&lt;CR&gt;~b</b>	- soft reset of only this board.
<b>&lt;CR&gt;~i</b>	- save PowerMAX OS state and enter the console
<b>&lt;CR&gt;~k</b>	- save PowerMAX OS state, enter the kernel debugger <b>kdb(1)</b> if it has been configured; otherwise enter the console.

## **Console Commands**

The remaining part of this chapter describes each of the console commands, with one or more examples of each command.

**a** **ASCII DUMP** **a**

**Purpose:** This command displays a portion of memory, NVRAM address space or PCI configuration space beginning at the specified location. The displayed data is in ASCII format and grouped by byte (**b**), word (**w**), or longword (**l**). This command has options (preceded by dashes) which are listed below. For a more detailed description of the options refer to the options paragraph in this chapter.

**Syntax:** **a**[*format*][**-b**<*n*>][**-p**|**-n**][*start\_address* [*end\_address*]]  
**a**[*format*][**-b**<*n*>][**-p**|**-n**][*start\_address*  
[**:***byte\_count*]]

**format** Determines whether the data appears in byte, word, or longword [**b**, **w**, or **l**] format or is to be byte reversed (**r**). If none specified, defaults to byte. (Note that for this command, a size greater than a byte makes little sense.)

**-b**<*n*> Specifies program base address. The base address <*n*> is added to all addresses entered from the command line (<*n*> is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The hexadecimal address at which the operation starts. The default value is 0.

**end\_address** The hexadecimal address at which the operation ends.

**:byte\_count** Number (in hexadecimal) of bytes displayed. The default is a page (256 bytes). Note that if you specify word format, **byte\_count** should be a multiple of two. If you specify longword format, **byte\_count** should be a multiple of four.

**repeaters** See the command manipulators paragraph for explanation.

**Examples:** The following are valid commands.

**a B0** Displays a page of data starting at location **B0**.

**ab 0** Displays a page of data starting at location **0**.

**al 100:10.** Displays the right–most byte of each of the four longwords of data starting at location 100. In other words, it displays the byte of data at memory locations 103, 107, 10B, and 10F.

**aw 0.** Displays right–most byte in each word starting at location 0.

**a0.** Displays from byte 0.

**ab 0 10.** Displays contents of addresses 0 through 10.

**a** ASCII DUMP (Continued) **a**

Sample ASCII dumps are shown below.

ASCII Dump by Byte with an Initial Address of 0

```
#0>ab 0.
00000000      H C- 1 . . . . . + u
00000010      . . . . . T [ . . . .
00000020      . . . . . d . R C S .
00000030      . . . 0 . . . . . 2 . o .
00000040      . . . @ . . . . . . . .
00000050      . . . P . . . . . . . + .
00000060      . . . \ . . . . . . . + .
00000070      . . . p . . . . . . . + .
00000080      . . . . . . . . . . + .
00000090      . . . . . . . . . T [ . . + .
000000A0      . . . . . . . . . d . . . + .
000000B0      . . . 0 . . . . . . . + .
000000C0      . . . @ . . . . . . . + .
000000D0      . . . P . . . . . . . 1 9 7
000000E0      . . . \ . . . . . . . 2 8 9
000000F0      . . . p . . . . . . . o . 4
```

ASCII Dump of Right-Most Byte in Each Word — Initial Address of 0

```
#0>aw 0.
00000000      C 1 . . . . . u
00000010      . . . . . [ . .
00000020      . . . . . C .
00000030      . 0 . . . . .
00000040      . @ . . . . .
00000050      . P . . . . .
00000060      . \ . . . . .
00000070      . p . . . . .
00000080      . . . . .
00000090      . . . . . [ . .
000000A0      . . . . .
000000B0      . 0 . . . . .
000000C0      . @ . . . . .
000000D0      . P . . . . 1 7
000000E0      . \ . . . . 2 9
000000F0      . p . . . . o 4
```

**a** **ASCII DUMP (Continued)** **a**

ASCII Dump by Longword

```
#0>a1 0.
00000000      1 . . u
00000010      . . [ .
00000020      . . . .
00000030      0 . . .
00000040      @ . . .
00000050      P . . .
00000060      \ . . .
00000070      P . . .
00000080      . . . .
00000090      . . [ .
000000A0      . . . .
000000B0      0 . . .
000000C0      @ . . .
000000D0      P . . 7
000000E0      \ . . 9
000000F0      P . . 4
```

ASCII Dump in Various Formats

```
#0>ab 0 :10.
00000000      H C P 1 . . . . . . . . . . + u
#0>ab 0 :4.
00000000      H C P 1
#0>aw 0 :4.
00000000      C 1
#0>a1 0 :4.
00000000      1
#0>ab 0 f.
00000000      H C P 1 . . . . . . . . . . + u
```

**b**

**LIST BREAKPOINTS**

**b**

**Purpose:** This command lists breakpoints for all of the processors.

**Function:** Some of the breakpoint commands have options (preceded by dashes) which are listed below. For a more detailed description of the options refer to the options paragraph in this chapter. Up to eight breakpoint entries are kept in an internal break address table.

**Syntax:** **b**

A sample list breakpoint command is shown below.

```
#0>b.  
00 00001000 CPU physical  
01 00002000 CPU physical
```

**b****SET BREAKPOINTS****b****Purpose:** This command sets breakpoints.**Function:** When the processor hits a breakpoint, the console removes the breakpoints from memory before accepting any commands. Some of the breakpoint commands have options (preceded by dashes) which are listed below. A more detailed description of options is provided earlier in this chapter.

Up to eight breakpoint entries are kept in an internal break address table. Overflow of the break address table generates an error message. When a program begins executing the system enters the breakpoints into the code.

**Syntax:** **b[-a][-o]<address>****-a** Immediately inserts all breakpoints into memory (that is, do not wait until a 'r'un command is executed before inserting the breakpoint set).**-o** Breakpoint is temporary. Temporary breakpoints are removed once they are hit.**address** The address to which a breakpoint is assigned. If you want to get a breakpoint at a processor address enter that particular address after the **b** command. If the **address** is already defined, an error message appears on the screen. If the address cannot be written, an error is generated.**Examples:** The following are valid commands.**b1000.** Set breakpoint at 0x1000**b hat\_icachesync.** Set breakpoint at the entry point to the kernel routine 'hat\_icachesync'.**b.or b<CR>** Displays breakpoint

**bk**

**CLEAR BREAKPOINTS**

**bk**

**Purpose:** This command clears (removes) breakpoints.

**Syntax:** **bk** <address>|<all>

**address** The address to which a breakpoint is assigned. If you want to clear a breakpoint at a processor address enter that particular address after the **bk** command.

**all** Remove all breakpoints

**Examples:** The following are valid commands.

**bk1000.** Remove breakpoint at 0x1000.

**bk start** Remove the breakpoint at the address when the label “start” is at.

**bk all** Removes all breakpoints.



c

## COPY MEMORY

c

**Purpose:** This command moves the data located at the **source\_start\_address** through **source\_end\_address** (inclusive) to the locations starting at the **destination\_start\_address**. This command also moves the data located at the **source\_start\_address** to the locations starting at the **destination\_start\_address** for the number of bytes specified in the **byte\_count**. This command has options (preceded by dashes) which are listed below. See the options paragraph in this chapter for more information.

**Note:** When virtual addressing is used, translation is performed in 'data' space.

**Syntax:** `c[format][-b<n>][-p|-n]`  
`<source_start_address><source_end_address>`  
`<destination_start_address>`

`c[format][-b<n>][-p|-n]`  
`<source_start_address>:<byte_count><destination_start_address>`

**format** Determines whether the data is to be copied in byte, word, or longword [**b**, **w**, or **l**] format (defaults to **l** if not specified). Though the byte ordering modifier **r** can be specified, it is basically a NOP for this command as the bytes will be reversed on each read, then re-reversed when written to the new memory location.

**-b<n>** Specifies program base address. The base address *<n>* is added to all addresses entered from the command line (*<n>* is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**source\_start\_address**

This is the address at which the memory to be copied starts.

**source\_end\_address**

This is the address at which the memory to be copied stops.

**destination\_start\_address**

This is the destination address.

**:byte\_count**

Number (in hexadecimal) of bytes copied. Note that if you specify word format, **byte\_count** should be a multiple of two. If you specify longword format, **byte\_count** should be a multiple of four.

**Examples:**

The following are valid commands.

`c B0 C0 D0` Moves data at locations **B0** through **C0** to location **D0**.

`cb 0 C0 D0` Moves values at locations **0** through **C0** to location **D0**.

**c**

**COPY MEMORY (Continued)**

**c**

Sample copy commands are shown below.

Move values byte by byte between 0 and 400 to 1000.

```
#0>cb0 400 1000. #0> d1000:10.  
00001000 00000000 00000004 00000008 0000000C
```

Move values word by word between 1000 and 1400 to 2000.

```
#0>cw1000 1400 2000. #0> d2000:10.  
00002000 00000000 00000004 00000008 0000000C
```

```
#0>cw2000:400 3000. #0>d3000:10.  
00003000 00000000 00000004 00000008 0000000C
```

**d** **DISPLAY MEMORY IN HEXADECIMAL** **d**

**Purpose:** This command displays a portion of memory, NVRAM address space or PCI configuration space beginning at the specified location. The displayed data is in hexadecimal format and grouped by byte, word, or longword.

**Note:** When virtual addressing is used, translation is performed in 'data' space.

**Syntax:** **d**[*format*][*-b*<*n*>][*-p*|*-n*]  
[*start\_address*[*end\_address*]]

**d**[*format*][*-b*<*n*>][*-p*|*-n*]  
*start\_address*[:*byte\_count*]]

**format** Determines whether the data is displayed in byte, word, or longword [**b**, **w**, or **l**] format (defaults to **l** if not specified). The default value is **w** in console mode and **l** in CPU mode (**o+p**). The byte ordering modifier **r** is only effective on **w** or **l** data formats and has no effect when reading PCI configuration space (see **-p** option below).

**-b**<*n*> Specifies program base address. The base address <*n*> is added to all addresses entered from the command line (<*n*> is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The hexadecimal address at which the operation starts. The default value is the last **start\_address** specified.

**end\_address** The hexadecimal address at which the operation ends.

**:byte\_count** Number of bytes displayed. The default is a page (256 bytes). Note that if you specify word format, **byte\_count** should be a multiple of two. If you specify longword format, **byte\_count** should be a multiple of four.

**repeaters** See the command manipulators paragraph for explanation.

**Examples:** The following are valid commands.

**d** Displays a page of data starting at location 0 in longword format (assumes CPU mode).

**d b0** Displays a page of data starting at location **B0**.

**db 0** Displays a page of data starting at location **0** in byte format.

**dw 0 4** Displays the first three words.

**d -n 1C000:a0** Displays the Console portion of the NVRAM.

**d -p 6100:30** Displays ethernet PCI configuration space register values.

**d                    DISPLAY MEMORY IN HEXADECIMAL (Continued)**

**d**

A sample of a hexadecimal memory display is shown below.

**HEXADECIMAL DISPLAY BY BYTE STARTING AT ADDRESS 0**

**#0>db 0.**

```

00000000 00 00 00 00 00 00 00 00 00 00 00 00 00 00 AB 75
00000010 00 00 00 10 00 00 00 00 1B 9D D4 5B 00 0C 00 02
00000020 00 00 00 20 00 00 00 00 1B 9D E4 0C 52 43 53 00
00000030 00 00 00 30 00 00 00 00 00 00 00 00 32 2E 6F 00
00000040 00 00 00 40 00 00 00 00 00 00 00 00 00 14 00 08
00000050 00 00 00 50 00 00 00 00 00 00 00 00 00 00 AB 8D
00000060 00 00 00 60 00 00 00 00 00 00 00 00 00 00 AB 8E
00000070 00 00 00 70 00 00 00 00 00 00 00 00 00 00 AB 8F
00000080 00 00 00 80 00 00 00 00 00 00 00 00 00 00 AB 90
00000090 00 00 00 90 00 00 00 00 1B 9D D4 5B 00 00 AB 84
000000A0 00 00 00 A0 00 00 00 00 1B 9D E4 0C 00 00 AB 92
000000B0 00 00 00 B0 00 00 00 00 00 00 00 00 00 00 AB 93
000000C0 00 00 00 C0 00 00 00 00 00 00 00 00 00 00 AB 94
000000D0 00 00 00 D0 00 00 00 00 00 00 00 00 00 31 39 37
000000E0 00 00 00 E0 00 00 00 00 00 00 00 00 00 32 38 39
000000F0 00 00 00 F0 00 00 00 00 00 00 00 00 2E 6F 00 34
    
```

**HEXADECIMAL DISPLAY BY WORD STARTING AT ADDRESS 1000**

**#0>dw 1000.**

```

00001000 0000 0000 0000 0000 0000 0000 0000 0000
00001010 0000 0000 0000 0000 0000 0000 1B9E 0E4C
00001020 0000 0000 0000 0000 0000 0000 1B9E 0E4C
00001030 0000 0000 0000 0000 0000 0000 0000 0000
00001040 0000 0000 0000 0000 0000 0000 0000 0000
00001050 0000 0000 0000 0000 0000 0000 0000 0000
00001060 0000 0000 0000 0000 0000 0000 0000 0000
00001070 0000 0000 0000 0000 0000 0000 0000 0000
00001080 0000 0000 0000 0000 0000 0000 0000 0000
00001090 0000 0000 0000 0000 0000 0000 1B9D CEBB
000010A0 0000 0000 0000 0000 0000 0000 1B9E 0E4B
000010B0 0000 0000 0000 0000 0000 0000 0000 0000
000010C0 0000 0000 0000 0000 0000 0000 0000 0000
000010D0 0000 0000 0000 0000 0000 0000 0000 0000
000010E0 0000 0000 0000 0000 0000 0000 0000 0000
000010F0 0000 0000 0000 0000 0000 0000 0000 0000
    
```

**d** DISPLAY MEMORY IN HEXADECIMAL (Continued) **d**

HEX DISPLAY STARTING AT ADDRESS 1000 — NO DATA SIZE SPECIFIED

```
#0>d1000. <—— Defaults to longword
00001000 00000000 00000000 00000000 00000000
00001010 00000000 00000000 00000000 1B9E0E4C
00001020 00000000 00000000 00000000 1B9E0E4C
00001030 00000000 00000000 00000000 00000000
00001040 00000000 00000000 00000000 00000000
00001050 00000000 00000000 00000000 00000000
00001060 00000000 00000000 00000000 00000000
00001070 00000000 00000000 00000000 00000000
00001080 00000000 00000000 00000000 00000000
00001090 00000000 00000000 00000000 1B9DCEBB
000010A0 00000000 00000000 00000000 1B9E0E4B
000010B0 00000000 00000000 00000000 00000000
000010C0 00000000 00000000 00000000 00000000
000010D0 00000000 00000000 00000000 00000000
000010E0 00000000 00000000 00000000 00000000
000010F0 00000000 00000000 00000000 00000000
```

COMPARE ASCII DISPLAY TO HEXADECIMAL DISPLAY

```
#0>wl 0 48 43 50 31. #0>ab 0 :10. <— Write hexadecimal data to memory.
00000000 . . . H . . . C . . . P . . . 1
#0>a1 0 :10.
00000000 H C P 1
#0>db 0 :10.
00000000 00 00 00 48 00 00 00 43 00 00 00 50 00 00 00 31
```

HEXADECIMAL DISPLAY BY WORD AT ADDRESS 1000

```
#0>dw 1000:10.
00001000 7c51 43a6 3c40 fff0 8842 fe20 5442 07be
```

HEXADECIMAL DISPLAY BY WORD AT ADDRESS 1000  
WITH LITTLE-ENDIAN BYTE ORDERING

```
#0>dwr 1000:10.
00001000 517C a643 403c f0FF 4288 20Fe 4254 be07
```

HEXADECIMAL DISPLAY BY LONGWORD AT ADDRESS 1000

```
#0>d1 1000:10.
00001000 7c5143a6 3c40fff0 8842fe20 544207be
```

HEXADECIMAL DISPLAY BY LONGWORD AT ADDRESS 1000  
WITH LITTLE-ENDIAN BYTE ORDERING

```
#0>dlr 1000:10.
00001000 a643517c f0ff403c 20fe4288 be074254
```

**di** **DISASSEMBLE MEMORY** **di**

**Purpose:** This command disassembles instructions beginning at the specified address. Note that when virtual addressing is used, translation is performed in 'instruction' space.

**Syntax:** **di**[-b<n>][-p|-n][start\_address[:byte\_count]]

**di**[-b<n>][-p|-n][start\_address [end\_address]]

**-b<n>** Specifies program base address. The base address <n> is added to all addresses entered from the command line (<n> is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The hexadecimal address at which the operation starts. The default value is the last **start\_address** specified.

**end\_address** The hexadecimal address at which the operation ends.

**:byte\_count** Number of bytes displayed. The default is 16 longwords (64 bytes).

Sample disassembly commands are shown below. Note that the symbol table must be loaded (bit 7 of register pboot i.e. **#0>pboot 80**), and a PowerMAX OS kernel or other bootable program booted to obtain the symbols shown in this display.

**#0>di %pc-10.**

```

000187b4 [000187b4] halt+34          70c31010 andi. r3,r6,1010
000187b8 [000187b8] halt+38          7c600124 mtmsr r3
000187bc [000187bc] halt+3c          4c00012c isync
000187c0 [000187c0] halt+40          4ea00421 bctrl
000187c4 [000187c4] halt+44          % 7cc00124 mtmsr r6
000187c8 [000187c8] halt+48          4c00012c isync
000187cc [000187cc] halt+4c          7ca803a6 mtlr r5
000187d0 [000187d0] halt+50          4ea00020 blr
000187d4 [000187d4] halt+54          48000004 b halt+0x58
000187d8 [000187d8] halt+58          48000004 b halt+0x5c
000187dc [000187dc] halt+5c          48000004 b consbkpt
000187e0 [000187e0] consbkpt         80801ff0 lwz r4,0x1ff0(r0)
000187e4 [000187e4] consbkpt+4       2c040000 cmpwi crf0,r4,0
000187e8 [000187e8] consbkpt+8       4082000c bne- crf0,consbkpt+0x14
000187ec [000187ec] consbkpt+c       38600001 li r3,1
000187f0 [000187f0] consbkpt+10      4ea00020 blr

```

Note that % implies the program counter of the default CPU and \* implies break.

**e** **EXAMINE/CHANGE MEMORY** **e**

**Purpose:** This command displays a byte, word, or longword of memory beginning at the specified memory location, NVRAM address space or PCI configuration space. This command can also change the data at that location and subsequent locations via the data specified. The format of the data written is controlled by the format and command options specified.

**Syntax:** **e[format][-b<n>][-p|-n][start\_address[data]]**

**format** Determines whether the data is displayed in byte, word, or longword [**b**, **w**, or **l**] format (defaults to **l** if not specified). The default value is **w** in console mode and **l** in CPU mode. The byte ordering modifier **r** is only effective on **w** or **l** data formats and has no effect even then if the **-p** option is specified.

**-b<n>** Specifies program base address. The base address **<n>** is added to all addresses entered from the command line (**<n>** is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The hexadecimal address at which the operation starts. The default value is 0.

**data** The new value to be entered at **start\_address**.

**repeaters** See the command manipulators paragraph for explanation.

**Examples:** The following are valid commands.

**e B0.** Displays a longword of data starting at location **B0**.

**eb 0.** Displays the byte of data at location **0**.

**ew0 5.** Displays the current word of data at location 0 and then changes the contents to 5.

**Sample examine and change commands are shown below.**

EXAMINE ONE BYTE AT ADDRESS 0

```
#0>eb 0.
00000000 00
```

EXAMINE ONE WORD AT ADDRESS 0

```
#0>ew 0.
00000000 0000
```

e **EXAMINE/CHANGE MEMORY (Continued)** e

EXAMINE MEMORY STARTING AT ADDRESS 0 – NO DATA SIZE SPECIFIED

#0>**e0** <CR><— Defaults to longword.  
 00000000 00000000 , <— The comma shows next longword.  
 00000004 AB0007FF. <— The period terminates command.

EXAMINE LONGWORD AT LOCATION 1000

#0>**e 1000**.  
 00001000 7c5143a6

EXAMINE WORD AT LOCATION 1000

#0>**ew 1000**.  
 00001000 7c51

EXAMINE WORD AT LOCATION 1000 IN LITTLE-ENDIAN BYTE ORDERING

#0>**ewr 1000**.  
 00001000 517c

EXAMINE WORD WITH VIRTUAL ADDRESS SPECIFIED

#0>**e (BFFF8000) <CR>**  
 BFFF800 [00018000] 00000000.

DEPOSIT A LONGWORD IN MEMORY AND VERIFY THAT THE VALUE WAS STORED

#0>**e10 <CR>**  
 00000010 7FFAB001 50 <— The user enters 50 and the console writes 50 to  
 location 10 and verifies that the value is actually  
 00000014 00000432 stored at 10.  
 #0>**e10 <CR>**  
 00000010 00000050. <— The user enters a period.

DEPOSIT A WORD OF DATA WITH THE BYTE PARAMETER

#0>**eb 10 <CR>**  
 00000010 00 123@<— The console displays an error message  
 error 0009: memory doesn't match  
 00000010 23. <— The period terminates the command.





**fb, fB**

**BOOT OPERATING SYSTEM (Continued)**

**fb, fB**

A sample system boot listing is shown below.

```
#0>fb <CR>
```

```
    dsk(3,0,0,0)/.  
Initialize VME  
    dsk(3,0,0,0)/stand/boot
```

```
    Boot  
: unix  
747336+61360+597388 start 0x4000
```

**fc****DISPLAY DIRECTORY****fc****Purpose:** This command lists the contents of the specified directory.**Note:** Never append a period to this command. After the command, you must press **<CR>**. (Periods are valid syntax in pathnames.)**Syntax:** **fc [dir\_name]****dir\_name** A directory name. If the **m** option of the **o** command is set (**o+m**) you must provide the device on which the directory is located.**Examples:** The following are valid commands.**fc/usr/d <CR>****fc/ <CR>**

A sample root directory listing is shown below.

#0>**fc / <CR>**

```

.
..                lost+found      usr                var
tmp               dev                sbin              etc
unix              bck                bin               export
home              install            installr          lib
mnt               opt                proc              save
shlib             stand              system             .profile
boot              idle               spare             tmp_rex
.sh_history       x.c                x

```

**fd** **DISPLAY/SET THE DEFAULT DEVICE** **fd**

**Purpose:** This command sets or displays the default device.

**Note:** Never append a period to this command. After the command, you must press a <CR>. (Periods are valid syntax in parameters.)

**Syntax:** **fd [-l][-s[w]][dev]**

**-l** List the logical device table. If this option is entered, do not enter **dev**. This option displays all of the available boot devices (tapes and disks) along with the logical device numbers. See examples below.

**-s** In addition to changing the default device locally, also save the selection in NVRAM. This makes the selection available across system resets to all future boots.

**-w** If saving to NVRAM, don't ask 'are you sure?'.

**dev** The device that is to be chosen as the default device. Two formats are available depending upon the number of fields in **dev**. The two field version is either **dsk(d,p)** or **mt(d,p)** where **d** is a logical device number and **p** is the partition number (0 through 6). Logical device numbers always run from 0 to n and correspond to the available boot devices found by the system during a search of all available SCSI controllers. The table of logical device numbers may be displayed via the **-l** option. The second format for **dev** provides an absolute hardware address and is input as **dsk(c,u,p,b)** or **mt(c,u,p,b)** where **c** is the controller number within the particular bus, **u** is the drive ID, **p** is the partition number (0 through 6) and **b** is the bus number (0 is normally the internal PCI bus, 1 is the VME bus and 2 is the IDE bus). To use the absolute mode, all four fields must always be entered. If you do not specify a device, the console assumes the two field version and selects **dsk(0,0)**.

**Examples:** The following are valid commands.

**fd mt(0)** Set the default device to the first tape device found on the various SCSI bus controllers in the system. Partition zero is selected by default.

**fd dsk(0,0,0,0)** Set the default device to the disk on SCSI ID 0 of the internal PCI bus SCSI controller.

**fd dsk(0,0,2,0)** Set default to 'usr' partition.

**fd DISPLAY/SET THE DEFAULT DEVICE (Continued) fd**

**fd -l** List the available devices and logical device numbers:

```
>fd -l
-----
fd          disk          tape
0  (2,0,x,1) FUJITSU M2624S-512(0,5,x,0) ARCHIVE VIPER 150 21247
1  (2,2,x,1) FUJITSU M2624F-512
-----
```

**Examples using the -s option:**

The following are valid commands using the **-s** option.

- fd -s** with no parameters specified, clears the default device
- fd -s dsk(1)** causes the second disk listed under **fd-l** to be used as the default boot device on subsequent system boots.

**Example of changing the default disk from drive 0 to drive 1:**

```
#0>fd
.....
dsk(0,0,0,0)
#0>fd -s dsk(1)
Update NVRAM (Y/N) ? y|
NVRAM updated
```

**Example of reverting back to drive 0 (default):**

```
#0>fd -s
Clearing default boot device.
Update NVRAM (Y/N) ? y
NVRAM updated.
```

**fh**    **DISPLAY MOUNTED FILE SYSTEMS**    **fh**

**Purpose:**   This command gives the default input device.

**Note:**      Never append a period to this command. After the command, you must press <CR>. (Periods are valid syntax in parameters.)

**Syntax:**   **fh**

A sample display from the **fh** command is shown below.

```
#0>fh <CR>
Default:                 dsk (5,0,0,0)
```

**f1**                                      **LOAD A PROGRAM**                                      **f1**

**Purpose:** This command loads a program. The file loaded must be a bit-for-bit binary image of what is to appear in memory, and its entry point is assumed to be the first word of the file. The command can be followed by an optional list of arguments that are to be passed to the program.

**Note:** Never append a period to this command. After the command, you must press <CR>. (Periods are valid syntax in parameters.)

**Syntax:** **f1 [-c<n>]<file\_name>[base]**

**-c<n>**                                      Specifies the CPU<n> on which the **f1** command is to run on. If none specified, defaults to the master CPU.

**file\_name**                                  A file specification, in the following format: [**dev**] **pathname**. This file contains the file to be loaded. If the **m** option of the **o** command is set (**o+m**), you must provide the device on which the directory is located via a **fd** command or by specifying **dsk/**.

**base**                                        The address into which the program is loaded. Programs are loaded at 0x4000 as a default. If, however, you specify a **base**, the load address and start address are set to the **base** value.

**Example:**                                  A sample load the boot program.

```
#0>f1 /stand/boot
```

**fr** **LOAD AND EXECUTE A PROGRAM** **fr**

**Purpose:** This command loads and executes a program. The file loaded must be a bit-for-bit binary image of what is to appear in memory, and its entry point is assumed to be the first word of the file. The command can be followed by an optional list of arguments that are to be passed to the program.

**Note:** Never append a period to this command. After the command, you must press **<CR>**. (Periods are valid syntax in parameters.)

**Syntax:** **fr [-c<n>]<file\_name>[base]**

**-c<n>** Specifies the CPU<n> on which the **fr** command is to run on. If none specified, defaults to the master CPU.

**file\_name** A file specification, in the following format: [**dev**] **pathname**. This file contains the file to be loaded. If the **m** option of the **o** command is set (**o+m**), you must provide the device on which the directory is located via a **fd** command or by specifying **dsk/**.

**base** The address into which the program is loaded. Programs are loaded and run at 0x4000 as a default. If, however, you specify a **base**, the load address and start address are set to the **base** value.

**Example:** A sample load the boot program and boot the system sequence is shown below.

```
#0>fr /stand/boot <CR>
```

```
Boot
: /stand/unix
2683832+297207+508045 start 0x4000
symbol table loaded
```

```
Concurrent PowerMAX_OS Release 5.0
```



g

## GENERAL REGISTER DISPLAY/MODIFY

g

**Purpose:** This command displays and/or modifies the contents of the 40 general-purpose registers of the default CPU as shown in Table 3-4. If no parameters are specified, this command displays all of the general purpose registers (e.g. pc, r0 through r3, etc.). If a register name with no **data** parameter is specified, the contents of that specific register is displayed. If the **data** parameter is included, the console changes the value in the register. Subsequent registers can be modified by specifying new data for that particular register. To display the registers, the CPU must be halted. After the CPU is halted, the data displayed is that obtained at the last CPU halt.

**Note:** This command is identical to the **p** command, except that if no register list is specified, the default set of registers listed is different.

**Syntax:** **g** [-c<n>]<register\_name>[data]

**Table 3-4. General-Purpose Registers**

REGISTER N	ACRONYM	TYPE
Program Counter	pc	R/W
Machine Status Register	msr	R/W
Register 0	r0	R/W
Register 1	r1	R/W
.	.	.
.	.	,
.	.	.
Register 31	r31	R/W
Condition Register	cr	R/W
Link register	lr	R/W
Count Register	ctr	R/W
Extension Register	xer	R/W
System CPU Level	spl	R/W

**-c<n>** Specifies the CPU<n> on which the command is to run on. If none specified, defaults to the attentive CPU.

**register\_name** The general-purpose register to be examined or changed.

**data** The new hexadecimal value to be entered at **register\_name**.

**repeaters** See the command manipulators paragraph for explanation.

g

## GENERAL REGISTER DISPLAY/MODIFY (Continued)

g

**Examples:** The following are valid commands.

**gpc.** Display contents of the program counter.

**gr1.** Display contents of data register r1.

**g.** Displays contents of all general registers.

An examine all general register values example is shown below.

```
#0>g
pc = 000187C4      msr = 00001010      cr = 48800000      spl = 00000061
r0 = 0000F084      r1 = FFD040B8      r2 = 00000000      r3 = 00001010
r4 = 00002000      r5 = 0021E554      r6 = 00009032      r7 = C22DE4F5
r8 = 00000001      r9 = 00000001      r10 = 002F2D19     r11 = 002F2D19
r12 = C22DE475     r13 = 0021E140     r14 = 002F2D19     r15 = 00000069
r16 = 003EFE48     r17 = 00000069     r18 = 00000069     r19 = 00000000
r20 = 00000001     r21 = FFD041FA     r22 = 00000001     r23 = 00000061
24 = 0000006C      r25 = 00009032     r26 = 00000000     r27 = 00000094
r28 = DEADBEEF     r29 = 00000020     r30 = 81818181     r31 = 0BADCODE
lr = 000187C4      ctr = 01FC7ED8      xer = 00000004
```

An examine and change register values example is shown below.

```
#0>gr1 <CR>          <—Displays contents of register r1.
r1 = C002F7F2,      <—Entering the comma displays r2.
r2 = 00000000,      <—Entering the comma displays r3.
r3 = 81A40001       <—Entering the period finishes command.
#0>gr2 23.81A40001 <—Change contents of r2 to 23.
#0>gr1 <CR>          <—Display register r1.
r1 = C002F7F2
r2 = 00000000,
r3 = 00000023.
```

**i** INITIALIZE MEMORY TO VALUE (FILL) **i**

**Purpose:** This command writes the **data** into all locations between the **start\_address** and **end\_address**. The format of the data is controlled via the options entered. Memory addresses before 0x6000 are used by the console and should not be initialized.

**Note:** When virtual addressing is used, translation is performed in 'data' space.

**Syntax:** `i[format][-b<n>][-p|-n]  
<start_address><end_address> [fill_value]`

`i[format][-b<n>][-p|-p]  
<start_address>:<byte_count> [fill_value]`

**format** Determines whether the data is displayed in byte, word, or long-word [**b**, **w**, or **l**] format (defaults to **l** if not specified). The default value is **w** in console mode and **l** in CPU mode. The byte ordering modifier **r** is only effective on **w** or **l** data formats. The **r** modifier flag has no effect if the **-p** option is also specified.

**-b<n>** Specifies program base address. The base address **<n>** is added to all addresses entered from the command line (**<n>** is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The address at which the loading of memory starts. This address may not be a virtual address.

**end\_address** The address at which the loading of memory ends. If the **end\_address** is not supplied or is a location before the **start\_address**, you get a syntax error. This address may not be a virtual address.

**:byte\_count** Number (in hexadecimal) of bytes initialized. Note that if you specify word format, **byte\_count** should be a multiple of two. If you specify longword format, **byte\_count** should be a multiple of four.

**fill\_value** The hexadecimal word that is loaded into each memory location. The fill value defaults to zero.

i INITIALIZE MEMORY TO VALUE (FILL) (Continued)

i

**Examples:**

The following are valid commands.

**ib -n 1C000:10 0**

Fill with zero part of the console area of the NVRAM.

**i10 20 10101010.** Loads each longword from 10 to 20 with the hexadecimal word 10101010.

**ib10 20 F.** Loads each byte from 10 to 20 with the hexadecimal value F.

Sample memory initialization procedures are shown below.

INITIALIZE MEMORY BETWEEN ADDRESSES 1000 AND 2000

#0>**i1000 2000 10101010.** #0>**d1000 :10.** <— *Defaults to longword hexadecimal display starting at address 1000.*

00001000 10101010 10101010 10101010 10101010

INITIALIZE MEMORY BETWEEN ADDRESSES 1000 AND 2000 (LOAD A WORD)

#0>**iw1000 2000 ff.** #0>**d1000:10.**

00001000 00FF00FF 00FF00FF 00FF00FF 00FF00FF

INITIALIZE MEMORY BETWEEN ADDRESSES 10 AND 20 (LOAD A BYTE)

#0>**ib10 20 f.** #0>**d10:10.**

00000010 0F0F0F0F 0F0F0F0F 0F0F0F0F 0F0F0F0F

**k**

**Kick CPUs**

**k**

**Purpose:** This command is used on multiprocessor systems to kick nonresponsive CPUs back into the console.

A CPU may be nonresponsive, for example, if it has blocked out interrupts.

The 'k' command functions by resetting (yanking on the SysReset pin) of the errant CPUs. There is always the risk the application state of "kicked" CPUs may be lost.

**Syntax:** k

**Examples:**

**k**

**m** **MEMORY TEST** **m**

**Purpose:** This command performs a combination of tests (ones, zeroes, and unique address) that checks memory, NVRAM address space or PCI configuration space between the **start\_address** and **end\_address**. Any errors which occur appear listed on the console screen.

**Note:** When virtual addressing is used, translation is performed in 'data' space.

**Syntax:** `m[format][-b<n>][-p|-n]  
[start_address][end_address>`  
  
`m[format][-b<n>][-p|-n]  
[start_address][:byte_count]`

**format:** Determines whether the data is displayed in byte, word, or long-word [**b**, **w**, or **l**] format (defaults to **l** if not specified). The byte ordering modifier **r** is only effective on **w** or **l** data formats.

**-b<n>** Specifies program base address. The base address *<n>* is added to all addresses entered from the command line (*<n>* is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The first address tested. This address may not be a virtual address.

**end\_address** The last address tested. This address may not be a virtual address.

**:byte\_count** Number (in hexadecimal) of bytes tested. Note that if you specify word format, **byte\_count** should be a multiple of two. If you specify longword format, **byte\_count** should be a multiple of four.

**Example:** The following is a valid command.

`m1000 2000.`

o GLOBAL COMMAND OPTIONS o

**Purpose:** This command sets conditions under which the console operates. These conditions are stored as options in an options word.

**Syntax:** o [+|-][a][m][v][-b<n>][-c<n>]

**+ or -** A plus (+) adds and a minus (-) removes the specified options from the options word, effectively enabling or disabling that option. If you do not use a plus or minus, the command sets the options word to the options specified. The options are the conditions under which the console operates. If you do not specify any options, the console displays the current options.

**a** Permit auto-rebooting of kernel on certain PowerMAX OS failures.

**m** Disables automatic translation and 'mount' of directory names to the corresponding file system devices. These devices allow system files to be available from the console across all system disks by system-wide pathnames.

**v** Defaults to virtual addresses whenever virtual memory is enabled. Brackets or parentheses may be used to override the default address mode.

**-c<n>** Change the attentive CPU to CPU<n>.

**-b<n>** Specifies program base address. The base address <n> is added to all addresses entered from the command line (<n> is zero by default).

**Examples:** The following are valid commands.

o. Display options that are set.

o+r Add r option.

o-vm Disable v and m options.

Sample set and remove options commands are shown below.

#0>o.<—Display current options.  
mr -b 0

#0>o+v.<—Add v option.  
o. mrv -b 0

**p** **PROCESSOR REGISTER DISPLAY/MODIFY** **p**

**Purpose:** This command displays and changes the contents of the 44 processor registers and the two pseudo-registers 'boot' and 'aboot' (see Table 3-5). If no parameters are specified, this command displays all of the processor registers. If a register name with no data is given, the contents of the specified register is displayed. If you specify the **data** parameter, the console changes the value in the register to the value specified. Processor registers and their attributes were discussed under the processor registers paragraph in this manual.

**Note:** This command is an alternative version of the **g** command.

**Syntax:** **p [-c<n>][<register\_name>[data]]**  
**p [-s[w] boot <flags>**  
**paboot<seconds>**

**-c<n>** Specifies the CPU<n> on which the command is to run on. If none specified, defaults to the master CPU.

**register\_name** The processor register to be examined or changed. The value of the **register\_name** is the symbolic register name.

**data** The hexadecimal data to be placed in the processor register.

**seconds** Where 'seconds' is the number of seconds to delay when autobooting an OS.

**flags** pboot values shown in Table 3-3 on 3-25. Values can be added together.

**Note:** The pseudo-registers 'boot' and 'aboot' are not real machine registers; they are memory locations within the console which can be viewed and/or changed with the 'p' command.

**Examples:** The following are valid commands.

**p.** Displays all processor registers.

**pboot** Displays contents of processor boot register (see **fb** command).

**pdar.** Displays contents of the Data Address Register.

An examine all processor register values example is shown below.

**#0>p.**

```

dsisr = 0A000000    dar = 3003B288    sdr1 = 01E0000F    fpscr = 000000D0
sr0 = 20000000    sr1 = 20DE2989    sr2 = 20DE298A    sr3 = 20DE298B
sr4 = 20DE298C    sr5 = 20DE298D    sr6 = 20DE298E    sr7 = 20DE298F
sr8 = 20DE2990    sr9 = 20DE2991    sr10 = 20DE2992    sr11 = 20DE2993
sr12 = 20DE2994    sr13 = 20DE2995    sr14 = 20000001    sr15 = 20000002
sprg0 = 002F0000    sprg1 = 20DEE9DE    sprg2 = FFD05000    sprg3 = FFD04400
ibat0u = 0000007E    ibat1u = 00000000    ibat2u = 00000000    ibat3u = 00000000
ibat0l = 00000003    ibat1l = 00000000    ibat2l = 00000000    ibat3l = 00000000
dbat0u = 0020003E    dbat1u = 00000000    dbat2u = 00000000    dbat3u = 00000000
dbat0l = 00200012    dbat1l = 00000000    dbat2l = 00000000    dbat3l = 00000000
dabr = 00000000    iabr = 00000000    hid0 = 00000000    l2cr = 00000000
boot = 00000982    aboot = 00000000
    
```



**p            PROCESSOR REGISTER DISPLAY/MODIFY (Continued)            p**

Sample commands that examine and change the processor registers are shown below.

**EXAMINE THE CONTENTS OF PROCESSOR REGISTER `dar`**

```
#0>p dar <CR>
dar = 00002000,
#0>
```

**CHANGE THE CONTENTS OF PROCESSOR BOOT REGISTER**

```
#0>p boot 982. 00000982
#0>p boot.00000982
```

**CHANGE THE CONSOLE BOOT DELAY TO 9 SECONDS**

```
#0>paboot 9
00000009
NVRAM updated
```

**Table 3-5. Processor Registers Accessed via p Command**

REGISTER NAME	ACRONYM	TYPE
about Register	about	R/W
Boot Register	boot	R/W
Data Storage Interrupt Status Register	dsisr	R/W
Data Address Register	dar	R/W
Floating Point Status Register	fpscr	R/W
Segment Register 0	sr0	R/W
Segment Register 1	sr1	R/W
Segment Register 2	sr2	R/W
Segment Register 3	sr3	R/W
Segment Register 4	sr4	R/W
Segment Register 5	sr5	R/W
Segment Register 6	sr6	R/W
Segment Register 7	sr7	R/W
Segment Register 8	sr8	R/W
Segment Register 9	sr9	R/W
Segment Register 10	sr10	R/W
Segment Register 11	sr11	R/W
Segment Register 12	sr12	R/W
Segment Register 13	sr13	R/W
Segment Register 14	sr14	R/W
Segment Register 15	sr15	R/W
Storage Description Register 1	sdr1	R/W
Special Register G0	sprg0	R/W
Special Register G1	sprg1	R/W
Special Register G2	sprg2	R/W
Special Register G3	sprg3	R/W
Instruction Batch Register 0 Upper	ibat0u	R/W
Instruction Batch Register 0 Lower	ibat0l	R/W
Instruction Batch Register 1 Upper	ibat1u	R/W
Instruction Batch Register 1 Lower	ibat1l	R/W
Instruction Batch Register 2 Upper	ibat2u	R/W
Instruction Batch Register 2 Lower	ibat2l	R/W
Instruction Batch Register 3 Upper	ibat3u	R/W
Instruction Batch Register 3 Lower	ibat3l	R/W
Data Batch Register 0 Upper	dbat0u	R/W
Data Batch Register 0 Lower	dbat0l	R/W
Data Batch Register 1 Upper	dbat1u	R/W
Data Batch Register 1 Lower	dbat1l	R/W
Data Batch Register 2 Upper	dbat2u	R/W
Data Batch Register 2 Lower	dbat2l	R/W
Data Batch Register 3 Upper	dbat3u	R/W
Data Batch Register 3 Lower	dbat3l	R/W
Data Address Breakpoint Register	dabr	R/W
Instruction Address Breakpoint Register	iabr	R/W
Hardware Implementation Dependent Reg 0	hid0	R/W
L2 Cache Control Register	l2cr	R/W

**qa** **QUERY ADDRESS** **qa**

**Purpose:** This command allows either the symbolic name of a specified address or the address of a specified symbolic name to be queried. The symbols table must have been previously loaded by setting bit 7 in the pboot register (e.g. **pboot 80.**) and issuing a **fb** command.

**Syntax:** **qa**<address>

**address**                   The address for which a symbol name is to be displayed.

**Example:**                The following are valid commands.

```
#0>qa C0066000 <CR>
hdiectl+2A0 (C0065D60+2A0)
```

```
#0>qa \hdiectl <CR>
hdiectl (C0065D60)
```

**qb**

**QUERY BACKPLANE**

**qb**

**Purpose:** This command displays processor status information.

**Syntax:** **qb**

A sample display from the **qb** command is shown below.

```
#0> qb
cpu alive down runnable halted stuck
-----
0      y  -      -      y  -  master attentive
1      y  -      -      y  -
```

Note:

alive	CPU is available for applications to use
down	user has marked CPU as unavailable
runable	CPU has application state associated with it
halted	CPU is idling in or executing Console code
stuck	CPU is stuck in uninterruptable application code
master	CPU Console does its best to run on
attentive	CPU whose application state Console is focused on

**qp** DISPLAY SPECIAL PURPOSE REGISTERS **qp**

**Purpose:** Displays the actual values of either every special purpose (SPR) register of some CPU, or displays selected SPRs across all CPUs.

**Syntax:** **qp** [-c<n>]  
**qp** reg reg ...

-c<n> Specifies the CPU<n> whose entire SPR register set is to be displayed.

**Examples:** The following are valid commands.

**qp -c0** Display s all the SPRs for CPU 0.

**qp msscr0 msscr1** Displays the value of these two SPRs for all CPUs.

**Note:** A special purpose register is any register given a SPR number by the PowerPC Architecture and can be referenced by the **mtspr** and **mfspr** instructions. This set includes some rather common registers, such as CTR IR, which are also reported by other console commands such as 'g' and 'p'.

qs

QUERY STACK

qs

**Purpose:** This command displays the stack of a program that has been booted by the console. The stack of the attentive CPU is displayed.

**Syntax:** qs [-c<n>]

**-c<n>** Specifies the CPU<n> whose stack is to be displayed. If none specified, defaults to the attentive CPU.

**Examples:** The following is a valid command.

#0>qs.

----- KERNEL STACK -----

```
          _cnputs() at C00639E6(_cnputs+6)
BFFFE9E2 _cnproc() at C0063908(_cnproc+200)
BFFFEA46 _ttwrite() at C006ACDA(_ttwrite+31E)
BFFFEA8A _raw_rw() at C0050416(_raw_rw+526)
BFFFEACA _write() at C002C680(_write+140)
BFFFE666 _syscall() at C004F2D2(_syscall+1F6)
BFFFE6B2 _Xtrap0() at C000C58E(_Xtrap0+1E)
```

**qv** **QUERY VIRTUAL ADDRESS** **qv**

**Purpose:** This command decodes and prints a virtual address.

**Syntax:** **qv** <virtual address>

**virtual address** The virtual address in question.

**Examples:** The following are valid commands.

### NOTE

Page tables should be loaded before expecting complete translations. This action may be accomplished via loading PowerMAX OS

```
#0>qv 187b4
** Fnd in ibat0 u=0x0000007e, l=0x00000003 (000187b4) pp=11
  Vaddr = 0x000187b4 SID=0x0
**1-PTE(0) @ 0x01e00600 = 80000000 00018010 (000187b4) pp=00
  1-PTE(1) @ 0x01e00608 = 00000000 00000000
  1-PTE(2) @ 0x01e00610 = 00000000 00000000
  1-PTE(3) @ 0x01e00618 = 00000000 00000000
  1-PTE(4) @ 0x01e00620 = 00000000 00000000
  1-PTE(5) @ 0x01e00628 = 00000000 00000000
  1-PTE(6) @ 0x01e00630 = 00000000 00000000
  1-PTE(7) @ 0x01e00638 = 00000000 00000000
  2-PTE(0) @ 0x01eff9c0 = 00000000 00000000
  2-PTE(1) @ 0x01eff9c8 = 00000000 00000000
  2-PTE(2) @ 0x01eff9d0 = 00000000 00000000
  2-PTE(3) @ 0x01eff9d8 = 00000000 00000000
  2-PTE(4) @ 0x01eff9e0 = 00000000 00000000
  2-PTE(5) @ 0x01eff9e8 = 00000000 00000000
  2-PTE(6) @ 0x01eff9f0 = 00000000 00000000
  2-PTE(7) @ 0x01eff9f8 = 00000000 00000000

#0>qv a00000
  Vaddr = 0x00a00000 SID=0x0
  1-PTE(0) @ 0x01e28000 = 00000000 00000000
  1-PTE(1) @ 0x01e28008 = 00000000 00000000
  1-PTE(2) @ 0x01e28010 = 00000000 00000000
  1-PTE(3) @ 0x01e28018 = 00000000 00000000
  1-PTE(4) @ 0x01e28020 = 00000000 00000000
  1-PTE(5) @ 0x01e28028 = 00000000 00000000
  1-PTE(6) @ 0x01e28030 = 00000000 00000000
  1-PTE(7) @ 0x01e28038 = 00000000 00000000
  2-PTE(0) @ 0x01ed7fc0 = 00000000 00000000
  2-PTE(1) @ 0x01ed7fc8 = 00000000 00000000
  2-PTE(2) @ 0x01ed7fd0 = 00000000 00000000
  2-PTE(3) @ 0x01ed7fd8 = 00000000 00000000
  2-PTE(4) @ 0x01ed7fe0 = 00000000 00000000
  2-PTE(5) @ 0x01ed7fe8 = 00000000 00000000
  2-PTE(6) @ 0x01ed7ff0 = 00000000 00000000
  2-PTE(7) @ 0x01ed7ff8 = 00000000 00000000
```

qy

QUERY BOOT OPTIONS

qy

**Purpose:** This command displays processor cache status

**Syntax:** qy

**Examples:** The following is a valid command.

#0>y0.

#0>qy.

```
yflags = 8c
ybit description          CPU 0 1 y  comments
-----
 1 L1 data cache OFF      n n n
 2 L1 insn cache OFF     n n n
 4 br history tbl OFF    y y y
 4 br prediction OFF     y y y
 8 L2 cache OFF          y y y
10 L2 copyback OFF       y y n  (2)
20 L2 data only ON       n n n
80 store gathering OFF   y y y
80 i&d speculative reads OFF y y y
```

2) some supported platforms do not permit L2 copyback to be enabled.  
This platform is one of those.



**r** EXECUTE RUN **r**

**Purpose:** This command starts the processor executing code. The initial program counter is either specified by the starting address or is taken to be the current value of the program counter.

**Function:** The **r** command inserts breakpoints and starts the processor executing at the [**start\_address**]. If [**start\_address**] is not specified, use the current program counter value as the starting address.

**Syntax:** **r**[-c<n>][**start\_address**]

**-c<n>** Specifies the CPU<n> on which the command is to run on. If none specified, defaults to the attentive CPU.

**start\_address** The address the processor jumps to. If you do not specify a **start\_address**, the value of the program counter is used.

**Example:** The following is a valid command.

**r4000** Runs the program whose first instruction presumably is at location 0x4000.

Additional examples of the run command are shown below.

```
#0>b \cnputs (breakpoint at _cnputs)
```

```
#0>r
```

```
Processor 0 breakpoint <CR>
```

```
C0083DE0 [00083DE0] \cnputs %*67FFF040 subu r31,r31,0x40
```

**ra** EXECUTE RUN TO ADDRESS **ra**

**Purpose:** This command starts the processor executing code. The initial program counter value is taken to be the current value of the program counter.

**Function:** The **ra** command creates a temporary breakpoint at **<address>**, inserts breakpoints, and starts the processor executing from current program counter.

**Syntax:** **ra [-c<n>] <address>**

**-c<n>** Specifies the CPU<n> on which the command is to run on. If none specified, defaults to the attentive CPU.

**address** The address of the application program the processor runs to.

**Example:** The following is a valid command.

```
#0>ra \cnrint2ecx (run to address of cnrint2ecx)
```

```
CPU 0 breakpoint  
C008251C [0008251C] cnrint2ecx %67FFF0480 subu r31,r31,0x480  
#0>
```

**rd** **RUN WITHOUT BREAKPOINTS** **rd**

**Purpose:** This command starts the processor executing code. The initial program counter is either specified by the starting address or is taken to be the current value of the program counter.

**Function:** The **rd** command starts the processor executing at [**start\_address**] without inserting breakpoints. If [**start\_address**] is not specified use the current program counter value as the starting address.

**Syntax:** **rd [-c<n>][start\_address]**

**-c<n>** Specifies the CPU<n> on which the command is to run on. If none specified, defaults to the attentive CPU.

**start\_address** The address of the application program the processor jumps to. If you do not specify a **start\_address**, the value of the program counter is used.

**Example:** The following is a valid command.

#0> **rd** Resumes execution of the program.

**rn** **RUN TO NEXT INSTRUCTION** **rn**

**Purpose:** This command starts the processor executing code. The initial program counter is either specified by the starting address or is taken to be the current value of the program counter.

**Function:** The **rn** command creates a temporary breakpoint at the address following the current instruction, insert breakpoints, and starts the processor executing at **[start\_address]**. If **[start\_address]** is not specified use the current program counter value as the starting address.

**Syntax:** **rn [-c<n>] [start\_address]**

**-c<n>** Specifies the CPU<n> on which the command is to run on. If none specified, defaults to the attentive CPU.

**start\_address** The address of the application program the processor jumps to. If you do not specify a **start\_address**, the value of the program counter is used.

**Example:** The following is a valid command.

```
#0> rn
CPU 1 breakpoint
C0082520 [00082520]   cnrint2ecx+4%   21DF0020   st.d
r14,r31,0x20
#0>
```

**rr** **RUN TO RETURN ADDRESS** **rr**

**Purpose:** This command starts the processor(s) executing code. The initial program counter is either specified by the starting address or is taken to be the current value of the program counter.

**Function:** The **rr** command creates a temporary breakpoint at the return address of the current C procedure, inserts breakpoints, and starts the processor(s) executing at [**start\_address**]. If [**start\_address**] is not specified use the current program counter value as the starting address.

**Warning:** In order to have this instruction function properly you must have executed the first (link) instruction.

**Syntax:** **rr** [-c<n>] [**start\_address**]

**-c<n>** Specifies the CPU<n> on which the command is to run on. If none specified, defaults to the attentive CPU.

**start\_address** The address of the application program the processor jumps to. If you do not specify a **start\_address**, the value of the program counter is used.

**Example:** The following is a valid command.

```
#0> rr
breakpoint: C00908F4

CPU 1 breakpoint
C00908F4 [000908F4] _lock_driv_sema+A4% F440580F or r2,r0,0x14
```

**s****SEARCH MEMORY FOR DATA****s**

**Purpose:** This command displays a range of 256 bytes of memory, NVRAM address space or PCI configuration space in hexadecimal beginning at **start\_address**. If the search routine locates the requested **pattern** in this page, it encloses the **pattern** with asterisks. Otherwise, it indicates that there is no match.

**Syntax:** **s**[**format**] [**-b**<**n**>][**-p**|**-n**][**r**]<**start\_address**>  
<**pattern**>[**mask**]

**format** Determines whether the data to be searched is in byte, word, or longword [**b**, **w**, or **l**] format (defaults to **l** if not specified). If you specify a byte format and have a longword pattern, the routine searches memory but does not find a match. The byte ordering modifier **r** is only effective on **w** or **l** data formats, and is ignored if the **-p** option is specified.

**Note:** Note that '**sr**' will be interpreted as the '**sr**' command, not as the '**s**' command with an '**r**' suffix.

**-b**<**n**> Specifies program base address. The base address <**n**> is added to all addresses entered from the command line (<**n**> is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The address at which the search starts.

**pattern** The pattern for which memory is searched. The pattern can be a byte, word, or longword.

**mask** The bit mask, which is a hexadecimal value that determines the part of each longword to be compared with the **pattern**. The mask can be any hexadecimal value from 00000000 to FFFFFFFF. Default is FFFFFFFF. Bit 1 sets the mask.

**Examples:** The following are valid commands.

**sb0 4** Search for a byte with pattern 4 starting at address 0.

Note: In the following examples, pattern matches are highlighted in bold type for illustration purposes.

s

SEARCH MEMORY FOR DATA (Continued)

s

Sample search procedures are shown below.

SEARCH FOR A BYTE WITH PATTERN 4 STARTING AT ADDRESS 0

#0>i 0 1000 0. #0>wb 15 4. #0>sb 0 4.

```

00000000 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000010 00 00 00 00 00 00*04*00 00 00 00 00 00 00 00 00
00000020 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000030 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000040 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000050 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000060 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000070 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000080 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00000090 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000000a0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000000b0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000000c0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000000d0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000000e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000000f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
#0>

```





**td** **CONFIGURE CPU DOWN** **td**

**Purpose:** This command is used on multiprocessor SBCs to mark down the specified CPUs. The **td** command with no arguments may be used to display the current set of 'up' and 'down' CPUs.

**Syntax:** **td [-s[w]] <cpu list> | all**

**-s** Save latest down state into NVRAM.

**-w** Save without asking 'are you sure?'

**all** Mark all but the master CPU down.

**Example:** The following is a valid command.

**td 1** Disable processor 1.

**td -sw 2** Disable processor 2, save list of all disabled processors into NVRAM and save without asking 'are you sure?'



**tu** **CONFIGURE CPU UP** **tu**

**Purpose:** This command is used on multiprocessor SBCs to mark up CPUs. The **tu** command with no arguments may be used to display the current set of 'up' and 'down' CPUs.

**Syntax:** **tu [-s[w]] all**  
**tu <CPU list>**

**-s** Save latest down state into NVRAM.  
**-w** Save without asking 'are you sure?'  
**all** Enables all processors.

**Example:** The following is a valid command.

**tu 1** Enable CPU 1.

**tu -sw 2 3** Mark CPU 2 and CPU 3 as 'up' and save the complete list of 'up' and 'down' CPUs into NVRAM.

**w** **WRITE DATA TO MEMORY** **w**

**Purpose:** This command writes the specified hexadecimal data to memory, NVRAM address space or PCI configuration space beginning at the **start\_address**. The format of the data written is controlled by the options used.

**Note:** When virtual addressing is used, translation is performed in 'data' space.

**Syntax:** **w[format][-b<n>][-p|-n]**  
**<start\_address><data0>[data1]...**

**format** Determines whether the data is written in byte, word, or longword [**b**, **w**, or **l**] format (defaults to **l** if not specified). Default is **w** in console mode, in processor mode. The byte ordering modifier **r** is only effective on **w** or **l** data formats, and is ignored if the **-p** option is specified.

**-b<n>** Specifies program base address. The base address **<n>** is added to all addresses entered from the command line (**<n>** is zero by default).

**-p** Address arguments are with respect to the PCI configuration space.

**-n** Address arguments are with respect to the NVRAM address space.

**start\_address** The hexadecimal address at which the writing starts.

**data0, data1** The data to be written to memory. The data must be hexadecimal. Note that multiple data locations can be specified.

**Examples:** The following are valid commands.

**wl -p 6104 0** Disables the onboard ethernet.

**wb0 2.** Writes a 2 to byte 0 of memory.

**wl0 3.** Writes a 3 to longword 0 of memory.

Sample write commands are shown below.

**WRITE BYTES TO MEMORY STARTING AT ADDRESS 0**

```
#0>wb0 1 2 3 4 5 6 7 8 9 a. #0>d0 10.
00000000 01020304 05060708 090A0000 00000000
00000010 00000000
```

**WRITE WORDS TO MEMORY STARTING AT ADDRESS 0**

```
#0>ww0 1 2 3 4 5 6 7 8 9 a. #0>d0 10.
00000000 00010002 00030004 00050006 00070008
00000010 0009000A
```

**y INITIALIZE y**

**Purpose:** This command initializes all and selects certain processor-specific configuration options. The flag bits for the **y** command are shown in Table 3-6.

**Syntax:** **y flags**

**flags** A numerical value which is the sum of the flag values shown in Table 3-6. below.

**Note 1:** The **y** command always saves its result into NVRAM.

**Note 2:** The **y** command also does a partial soft reset. After its execution, no application state is valid.

**Table 3-6. y Command Flag Bits**

Bit	Flag	Effect
B0	001	Disable data cache
B1	002	Disable instruction cache
B2	004	Disable branch history table
B3	008	Disable L2 cache
B4	010	Disable L2 copyback/Enable write through
B5	020	Disable use of L2 by instructions
B6	040	Disable use of L2 by data (PPC 7400 only)
B7	080	Disable store gather and speculative reads

**Sample initialization commands are shown below.**

#0>**y0** Initializes system with all caches enabled on all processors.

#0>**yb** Initializes system and disables data, instruction, and L2 caches on all processors.

**z** **SINGLE-STEP PROCESSOR** **z**

**Purpose:** This command single-steps a single processor one instruction at a time. Breakpoints are inserted into memory. Any pending interrupts are executed before returning control to the console.

**Syntax:** **z** [-c<n>][start\_address]

**-c<n>** Single step the specified CPU<n>. If not specified, the attentive CPU will be stepped.

**start\_address** The address of the instruction to single step. If you omit the **address**, the value of the program counter is used.

**Examples:** The following are valid commands.

```
#0>z
CPU 0 single step
C0082520 [00082520] _cnrint2ecx+4% 21DF0020 st.d r14,r31,0x20
(Note that C0082520 is the next instruction to execute.)
```

```
#0>z
CPU 0 single step
C0082524 [00082524] _cnrint2ecx+8% 221F0028 st.d r16,r31,0x28
```

```
#0>z
CPU 0 single step
C0082528 [00082528] _cnrint2ecx+C% 225F0030 st.d r18,r31,0x30
```

```
#0>z -c1
CPU 1 single step
000473dc [0004D3dc] lcad+4 % 7da80206 mflr r13
```

? **HELP COMMAND** ?

**Purpose:** The help command displays a basic list of all the console commands. You can obtain more information about a command by following the question mark (?) with the command letter or another ?. The help command is available immediately following power-up. Examples of the help command are shown below. The ? command displays help and/or global dash options.

**Syntax:** ? List of commands.

? a short help overview  
 ?? a much longer help overview  
 ?e help on the 'e' command (substitute any other command name for 'e')  
 ?- help on the most common command line options  
 ?\* help on the most common command line editor

**Example:** The following are valid commands.

```
a(scii dump)
b(reakpoint)
c(opy memory)
d(isplay memory in hex)
di(sassemble memory)
e(xamine/change memory)
f(ile operations): fb(oot) fl(oad) fr(un) fc(directory list)
etc
g(eneral register display/modify)
i(nitalize memory to value)
k(ick CPUs)
m(emory test)
o(ptions)
p(rocessor register display/modify)
q(uey)
r(un)
s(earch memory)
t(configure)
w(rite data to memory)
y(initialize)
z(single step)
~b(reboot machine)
?(help) ??(more help) ?-(option help) ?*(cmd line editor help)
```

```
#0>?a
a(scii dump)
a[b|w|l][r][-b][-p|-n][start_address [end_address]]
a[b|w|l][r][-b][-p|-n][start_address [:byte_count]]
```

? **HELP COMMAND (Continued)** ?

#0>??  
?(help)

An expression can be one or more numeric values separated by the arithmetic operators: plus(+) or minus(-).

numeric value

hex digits - hexadecimal number  
\$ - last address value  
% - contents of program counter  
%regname - contents of processor register  
'regname - address of processor register  
[\\]symbol - address of symbol  
BnBn - binary bits  
'n' - ascii value

address value

value - address  
[value] - physical address  
(value) - virtual address  
\*value:size - indirect address  
\*[value]:size - indirect physical address  
\*(value):size - indirect virtual address

?<cmd> - help on <cmd>  
?- - help on command options

#0>?-  
-(local per command options)  
-p - perform in pci cfg space  
-n - perform in nvram space  
-s - store into nvram where appropriate  
-w - when storing, don't ask `are you sure?'  
-c<n> - execute on cpu 'n'  
-r<n> - execute 'n' times (0 = infinite times)

#0>?\*  
\*(command line editor keystrokes)  
^f,^b - move forward/backward one character  
^a,^e - move to beginning/end of line  
del,^d - delete one character  
^h - delete prev character  
^n - recall next input line  
^p - recall previous input line  
^r,^l - redisplay input line  
^k - delete to end of input line  
^u - delete entire input line



# A

## Command Summary

---

The following is an alphabetical list of the console commands along with their definition and syntax.

### -A-

#### ASCII Dump

a[b|w|l][r][-b<n>][-p|-n][start\_address [end\_address]]  
a[b|w|l][r][-b<n>][-p|-n][start\_address [:byte\_count]]

### -B-

#### Breakpoints (List)

b

#### Breakpoints (Set)

b [-a] [-o] <address>

#### Breakpoints (Clear)

bk <address> | <all>

### -C-

#### Copy Memory

c[b|w|l][r][-b<n>][-p|-n]<source\_start\_address><source\_end\_address>  
<destination\_start\_address>

c[b|w|l][r][-b<n>][-p|-n]<source\_start\_address>:<byte\_count>  
<destination\_start\_address>

### -D-

#### Display Memory in Hexadecimal

d[b|w|l][r][-b<n>][-p|-n][start\_address [end\_address]]  
d[b|w|l][r][-b<n>][-p|-n][start\_address [:byte\_count]]

#### Disassemble Memory

di [-b<n>][-p|-n][start\_address [end\_address]]  
di [-b<n>][-p|-n][start\_address [:byte\_count]]

**-E-**

**Examine/Change Memory**

e[b|w|l][r][-b<n>][-p|-n][start\_address[data]]

**-F-**

**Boot Operating System**

fb [-c<n>][-q]  
fB [-c<n>][-q] bootfile

**Display Directory**

fc [dir\_name]

**Display/Set the Default Device**

fd [dev]

fd [-l]

fd [-s[w]][dev]

**Display Mounted File Systems**

fh

**Load a Program**

fl [-c<n>] <filename>

**Load and Execute a Program**

fr [-c<n>] <filename>[address]

**-G-**

**General Register Display/Modify**

g [-c<n>][<register\_name>[data]]

**-I-**

**Initialize Memory to Value (Fill)**

i[b|w|l][r][-q][-b<n>][-p|-n]<start\_address><end\_address>[fill\_value]  
i[b|w|l][r][-q][-b<n>][-p|-n]<start\_address>;<byte\_count>[fill\_value]

**-K-**

**Kick CPUs**

k

**-M-**

**Memory Test**

m[b|w|l][r][-b<n>][-p|-n]<start\_address><end\_address>  
 m[b|w|l][r][-b<n>][-p|-n]<start\_address>:<byte\_count>

**-O-**

**Global Command Options**

o [+|-][-a][-m][v][-b<n>][-c<n>]

**-P-**

**Processor Register Display/Modify**

p [-c<n>][<register\_name>[data]]  
 p [-s[w]] boot <flags>

**-Q-**

**Query Address**

qa <address>

**Query Backplane**

qb

**Query Stack**

qs[-c<n>]

**Query Virtual Address**

qv <virtual address>

**Query Boot Options**

qy

**-R-**

**Run (Execute)**

r [-c<n>][start\_address]

**Run (Execute to Address)**

ra [-c<n>]<address>

**Run Without Breakpoints**

rd [-c<n>][start\_address]

**Run to Next Instruction**

rn [-c<n>][start\_address]

**Run to Return Address**

rr [-c<n>][start\_address]

**-S-**

**Search Memory for Data**

s[b|w|l][r][-b<n>][-p|-n][r]<start\_address><pattern>[mask]

**Search Memory Range for Data**

sr[-b|w|l][r][-b<n>][-p|-n]<start\_address> <end\_address><pattern>[mask]  
sr[-b|w|l][r][-b<n>][-p|-n]<start\_address>:<byte\_count><pattern>[mask]

**-T-**

**Configure CPU Down** (Multiprocessor SBCs Only)

td <cpu>

**Configure Master CPU**

tm masterCPU [attentiveCPU]

**Configure CPU Up** (Multiprocessor SBCs Only)

tu [-s[w]] <cpu>

tu [-s[w]] all

**-W-**

**Write Data to Memory**

w[b|w|l][r][-b<n>][-p|-n]<start\_address><data0>[data1]

**-Y-**

**Initialize**

y [-c<n>]flags

-Z-

**Single-Step Processor**

z [address][-c&lt;n&gt;]

-?-

**Help Command**

? a short help overview  
 ?? a much long help overview  
 ?e help on the 'e' command  
 ?- help on command line options  
 ?\* help on the command line editor  
 - help on global options.

The following is a list of the console commands by function.

**REGISTER AND MEMORY MANIPULATION****ASCII Dump**

a[b|w|l][r][-b<n>][-p|-n][start\_address [end\_address]]  
 a[b|w|l][r][-b<n>][-p|-n][start\_address [:byte\_count]]

**Copy Memory**

c[b|w|l][r][-b<n>][-p|-n]<source\_start\_address><source\_end\_address>  
 <destination\_start\_address>  
 c[b|w|l][r][-b<n>][-p|-n]<source\_start\_address>:<byte\_count>  
 <destination\_start\_address>

**Display Memory in Hexadecimal**

d[b|w|l][r][-b<n>][-p|-n][start\_address [end\_address]]  
 d[b|w|l][r][-b<n>][-p|-n][start\_address[:byte\_count]]

**Disassemble Memory**

di [-b<n>][-p|-n][start\_address [end\_address]]  
 di [-b<n>][-p|-n][start\_address [:byte\_count]]

**Examine/Change Memory**

e[b|w|l][r][-b<n>][-p|-n][start\_address[data]]

**General Register Display/Modify**

g [-c<n>][-s[w]] [<register\_name>[data]]

**Initialize Memory to Value (Fill)**

i[b|w|l][r][-q][-b<n>][-p|-n]<start\_address><end\_address>[fill\_value]  
i[b|w|l][r][-q][-b<n>][-p|-n]<start\_address>:<byte\_count>[fill\_value]

**Memory Test**

m[b|w|l][r][-b<n>][-p|-n]<start\_address><end\_address>  
m[b|w|l][r][-b<n>][-p|-n]<start\_address>:<byte\_count>

**Processor Register Display/Modify**

p [-c<n>][-s[w]] [<register\_name>][data]]  
p [-s[w]] boot <flags>

**Search Memory for Data**

s[b|w|l][r][-b<n>][-p|-n]<start\_address><pattern>[mask]

**Search Memory Range for Data**

sr[-b|w|l][r][-b<n>][-p|-n]<start\_address> <end\_address><pattern>[mask]  
sr[-b|w|l][r][-b<n>][-p|-n]<start\_address>:<byte\_count><pattern>[mask]

**Write Data to Memory**

w[b|w|l][r][-b<n>][-p|-n]<start\_address><data0>[data1]

**FILE OPERATIONS**

**Boot Operating System**

fb [-c<n>][-q]  
fB [-c<n>][-q] bootfile

**Display Directory**

fc [dir\_name]

**Display/Set the Default Device**

fd [dev]  
fd [-l]  
fd [-s[w]] [dev]

**Display Mounted File Systems**

fh

**Load a Program**

fl [-c<n>]<filename>[address]

**Load and Execute a Program**

fr [-c<n>]<filename>[address]

**EXECUTION**

**List Breakpoints**

b

**Set Breakpoints**

b [-a] [-o] [-b<n>] <address>

**Clear Breakpoints**

bk <address> | <all>

**Execute Run**

r[start\_address]

**Execute Run To Address**

ra <address>

**Run Without Breakpoints**

rd [start\_address]

**Run To Next Instruction**

rn [start\_address]

**Run to Return Address**

rr [start\_address]

**Single-Step Processor**

z [address]

## HELP

### Help Command

?	a short help overview
??	a much long help overview
?e	help on the 'e' command
?-	help on command line options
?*	help on the command line editor
-	help on global options.

## MISCELLANEOUS

### Global Command Options

o [+][-][-a][-c<n>][m] [r] [v][-b<n>]

### Query Address

qa<address>

### Query Backplane

qb

### Query Stack

qs[-c<n>]

### Query Virtual Address

qv<virtual address>

### Query Boot Options

qy

### Configure CPU Down (Multiprocessor SBCs Only)

td [-s][-w]<CPU list>

### Configure CPU Up (Multiprocessor SBCs Only)

tu [-s[w] all

### Configure Master CPU (Multiprocessor SBCs Only)

tm masterCPU [attentiveCPU]



**Initialize**

y flags

Table A-1 lists the command parameters, range and their definitions.

**Table A-1. Command Parameter Definitions**

Parameter	Range	Comment
address		Can be any valid physical or virtual address (if the <b>o+v</b> option is set), including the device address.
base		The address into which the program is loaded. Default is 2000
byte_count		Number of bytes displayed.
data	[00000000–FFFFFFFF]	Data to be passed to the program. This data is format dependent.
dev	mt(c,u,p,b) dsk(c,u,p,b) where c = slot number; u=unit on controller 'c'; p=partition number (0–7); b=bus number where 0 = PCI and 1 = VME	The device that is used by the command.
dir_name		The directory name.
destination_start_address		The address where the destination is started
end_address		The address at which the operation stops.
fill_value	[00000000–FFFFFFFF]	The value that is loaded into each memory location.
format	[ <b>b</b> , <b>w</b> , or <b>l</b> ] [ <b>r</b> ]	The amount of bits that the data appears in. Formats are byte, word, or longword ( <b>b</b> , <b>w</b> , or <b>l</b> ) Default is Big-Endian display; <b>r</b> specifies Little-Endian display.
mask		The bit mask is a hexadecimal value that determines which part of each longword is to be compared with the pattern.
options	<b>-b&lt;n&gt;</b> , <b>-c&lt;n&gt;</b> , <b>-n</b> <b>-p</b> , <b>-o</b> , <b>-s</b> <b>-w</b>	The conditions the console operates under.
pattern	[00000000–FFFFFFFF]	The pattern for which memory is searched.

**Table A-1. Command Parameter Definitions (Cont.)**

Parameter	Range	Comment
register_name	pc, msr, cr, spl, r0– r31, lr, ctr, xer, mq, tid, dsisr, dar, fpscr, sr0-sr15, sdr0, sdr1, eim0, eim1, eis0, eis1, 23	The name of a register.
spec		A file specification, in the following format: [ <b>dev</b> ] <b>pathname</b> . This file contains the file to be loaded. If the <b>m</b> option of the <b>o</b> command is set ( <b>o+m</b> ), you must provide the device on which the directory is located via a <b>fd</b> command or by specifying <b>dsk/</b> .
start_address		The address at which the operation starts.

# B

## Error Codes

---

The following is a numerical list of the console error codes that may appear on the screen whenever a console command is executed and an error is detected.

### Debugger Error Codes

#### **error 0001: syntax error**

The command entered contained a syntax error. Use the help command to obtain the correct syntax (e.g., **?d**).

#### **error 0002: undefined symbol**

The symbol name used is not defined or the symbols are not loaded. If trying to reference a processor symbol, ensure that the console is in the processor mode (**o+p**) and the processor symbol table has been loaded. To load processor symbols, bit 7 of the pboot register must be set (e.g., **pboot 80.**) before issuing the **fb** or **fr** command.

#### **error 0003: starting address must be less than ending address**

When specifying an address range, the second address must be greater than the first address. To specify a byte count instead of an ending address use a colon **:** (e.g., **d 100:10**).

#### **error 0004: illegal CPU number**

The processor number used is not a valid processor. Ensure that the processor number is a processor and the processor is marked **'up'**. The **qb** command may be used to query the current configuration.

#### **error 0005: invalid stack frame**

The **rr** command requires that a valid stack frame exists to enable a return address to be extracted. Ensure that the processor has executed the link instruction of the current C procedure.

#### **error 0006: date/time format: y/m/d h:m:s**

When setting the time of century clock, the format of the date and time was incorrect. The correct format is: *y/m/d h:m:s*.

#### **error 0007: duplicate breakpoint**

An attempt was made to set a breakpoint at an address that already contained a breakpoint. To correct this situation, remove the old breakpoint first with a **bk** command.

**error 0008: breakpoint table full**

An attempt was made to set a breakpoint when eight breakpoints already exist. A maximum of eight breakpoints may be set at any one time. To correct this situation remove an existing breakpoint before setting the new one.

**error 0009: memory doesn't match**

While using the **e** command, data read does not match data written. The **e** command always verifies that it can read any data that it writes.

**error 000B: illegal option**

An illegal option letter was specified on the **o** command. A list of legal options may be displayed by typing **?o**.

**error 000C: illegal register**

The register name specified after the **%** was not a valid register name. Use the **g** and **p** command to obtain a complete list of valid register names. If trying to reference a processor register, ensure that the console is in the processor mode (**o+p**).

**error 000D: no symbol for address**

An address was specified on a command that did not correspond to a symbol name. Ensure that the correct mode processor (**o+p**) or **CP (o-p)** is set. Also ensure that the symbol table is loaded. To load processor symbols, bit 7 of the **pboot** register must be set (e.g., **pboot 80**.) before issuing the **fb** or **fr** command.

**error 000F: illegal option '-n'**

An illegal option **n** was used on a command. Use the help command to obtain a list of legal options for the command.

**error 0010: option '-n' requires an argument**

The option **n** requires an argument. Ensure that there is no space between the option letter and the argument (e.g., **-c3** is correct, **-c 3** is wrong). Use the help command to get a list of legal options for the command.

**error 0011: console locked**

An attempt was made to use the console when it was disabled at the control panel switch. Before using the console, it must be enabled at the control panel switch.

**error 0012: unable to access memory using backplane**

The console is unable to access system memory using the backplane. Most likely system memory is not functional. Use the **m** command to verify system memory.

**error 0013: failed to load/boot**

The **fb** command was unable to load the program "boot" from the default boot device. Ensure that the correct boot device is selected with the **fd** command.

**error 0014: low tocc battery**

When accessing the time of century clock (TOCC), the console detected a low battery. To correct this problem, replace the TOCC battery.

**error 001B: bad device or pathname**

An invalid device name or pathname was specified on one of the **f** commands. Ensure that the pathname starts with a slash /. Use the help command **?f** to verify the correct syntax is being used. The device must be either **dsk(c,u,p,b)** or **mt(c,u,p,b)** (e.g., **fd dsk(0)**, **fd mt(0)**).

Where: **c** – controller number  
**u** – unit number (optional)  
**p** – partition number (optional)  
**b** – bus number (optional) (0=primary).

**error 0020: read failed, offset x**

A disk or tape read at byte offset *x* failed. To correct this problem, try a different disk or tape drive.

**error 0021: open failed**

The open of a disk or tape failed.

**error 0022: n in open**

An illegal bus was specified on a **f** command. Use a **0** to specify the primary bus, and a **1** for the secondary bus. Ensure that the bus exists. Use the **qb** command to query the system configuration.

**error 0022: n in open**

A device type other than 'dsk' or 'mt' was used.

**error 0023: not a directory**

Either an I/O error occurred or the device does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command.

**error 0027: CPU x failed to single step**

The console single steps a processor by setting the trace bit in the **sr** register and running that particular processor. If the processor does not take a trace exception within one second, the single step fails. This error most frequently occurs with the **z** command, but it can also occur with the **r** command. The **r** command uses single stepping to skip over breakpoints.

**error 0029: a: expected n, actual m**

A memory test detected an error at address *a*. The value *n* was written to memory and the value *m* was read back.

**error 002A: All CPUs must be halted**

An **f** command was attempted when one or more processors were running. All of the processors must be halted with the **h** command before initiating an **f** command.

**error 002E: invalid memory destination**

An internal error occurred in the console which caused it to perform an invalid memory reference. Reset the console with **<CR>~b** and retry the command.

**error 002F: register 'n' is read only**

An attempt was made to modify processor register *n*. Register *n* is a read only register and may not be modified.

**error 0030: CPU must be running**

A command was attempted that expected a running processor. If a **tu** command (applicable to multiprocessor SBCs only) was being attempted use the **r** command instead.

**Console Debugger Error Codes**

**error 0201: boot script missing**

A script by the name 'boot' should always exist. The 'boot' script gets executed at power up and should contain commands to boot the operating system. The default 'boot' script contains the command **fb**.

**error 0202: slot n is not valid**

A command referenced slot *n* that was either empty or did not contain a board of the proper type. Use the **qb** command to display the hardware configuration of the system.

**error 020F: invalid segment descriptor, vaddr=n**

While translating virtual address *n* to a physical address, the console referenced an invalid segment descriptor in system memory. Ensure that the crp and segment descriptor are valid.

**error 0210: page not in memory, vaddr=n**

While translating virtual address *n* to a physical address, the console detected that the page containing the virtual address was not in system memory. Since the page is not in memory the data in this page is not accessible to the console. Ensure that the virtual address is within the bounds of the memory allocated to be accessed by the console.

**error 0264: CPU n marked down**

For multiprocessor SBCs only. Processor *n* was marked down due to either a **td** command or the detection of an error. The up/down status of a processor can be checked via the **qb** command.

**error 0265: CPU n is not valid**

A command referenced a processor that does not exist. Use the **qb** command to display the system hardware configuration.

**error 0267: vaddr (n) is supervisor protected**

An attempt was made to perform a virtual address translation in user space, and that address was marked as supervisor – protected.

**error 0268: (bata) probe operation failed on CPU n**

The console instructed a secondary processor to perform a memory management unit probe operation to check for BATC valid translation at a given address. No response was received.

**error 0280: CPU n failed to acknowledge DCB request**

The console could not communicate with processor *n*.

**error 0281: CPU n failed to set DCB done bit**

Processor *n* did not complete a console request.

**I/O Error Codes****error 0601: null path**

An internal console error occurred when the console was opening a file. Reset the console with **<CR>~b** and retry the command.

**error 0602: file not found**

An attempt was made to open a file that does not exist. Ensure that a valid pathname was specified. Use the **fc** command to verify that the file exists. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0603: block number negative**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0604: block number overflow**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0605: indirect block number void**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0606: block number void**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0607: not a directory**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0608: zero length directory**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 060E: cannot write files**

An attempt was made to write a file. The console does not support device writes. This error code should not occur under normal operating conditions and therefore it indicates an operator error. Reset the console with **<CR>~b** and retry the command.

**error 060F: no more file slots**

An internal console error occurred while opening a file. Reset the console with **<CR>~b** and retry the command. If error still occurs, suspect a corrupted file.

**error 0610: no more disk buffers**

An internal console error occurred while allocating a disk buffer. This error code should not occur under normal operating conditions and therefore it indicates an operator error. Reset the console with **<CR>~b** and retry the command.

**error 0611: super block read error**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0612: read error**

An I/O read error occurred. Previous message should indicate type of error.

**error 0613: zero length directory record**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0614: bad magic number in super block**

The device being read does not contain a valid file system. Verify that the disk or tape contains valid data and retry the command. Reset system via the **fd** command to ensure that the media is properly partitioned. Suspect corrupt file, rerun from a back-up file.

**error 0615: CP system device unavailable, retrying**

The console was unable to open the boot device during a **fb** command. The console attempts 12 retries then stops trying. Ensure that at least one Generic Disk (GD) disk controller exists in the primary I/O bus and the disk is spun up and ready.



**640 Series Console Errors**

These error codes (0640 through 064F) apply to the Concurrent SCSI Adapters, Generic Disk (GD), and Generic Tape (GT) devices, and the definition of the symptom will reflect which controller is displaying the error code. For example, if **error 0645: NCR Controller not found** is displayed on the console terminal, then the NCR controller is the source of the error code. However, if the generic disk controller is indicating this same error: **error 0645: GD:Controller not found** is displayed on the console terminal.

**error 0640: \_\_\_: No error**

This error can only result from an internal hardware or software error.

**error 0641: \_\_\_: Interface not configured**

This error results from selecting a disk or tape device that is not valid for this machine type. Use the **fd** command to select an appropriate device type.

**error 0642: \_\_\_: Invalid Command**

This error can only result from an internal hardware or software error.

**error 0643: \_\_\_: Unsupported command**

This error can only result from an internal hardware or software error.

**error 0644: \_\_\_: Bad device specification**

This error results from selecting a disk or tape device that is not valid. Use the **fd** command to select an appropriate device type.

**error 0645: \_\_\_: Controller not found**

This error results when an invalid controller number has been provided as part of a device specification. Use the **fd** command to select an appropriate controller number (0 through 9).

**error 0646: \_\_\_: Device not found**

This error results when the device was not found at the specified hardware address. Use the **fd** command to select a new device address.

**error 0647: \_\_\_: Device type mismatch**

This error results when the device specification referred to a disk (tape) when the real device found at that address was a tape (disk). Ensure that the correct address was used with the **fd** command.

**error 0648: \_\_\_: Controller timed out**

This error results when a I/O controller (NCR or IS) or device malfunctions, or an internal software error occurs. Suspect the I/O controller or device malfunction. Reset the system and retry the command.

**error 0649: \_\_\_: Controller reports fatal error**

This error results when a I/O controller (NCR or IS) or device malfunctions, or an internal software error occurs. Suspect the I/O controller or device malfunction. Reset the system and retry the command.

**error 064A: \_\_\_: Unrecovered device error**

This error results when a I/O controller (NCR or IS) or device malfunctions, or an internal software error occurs. Suspect the I/O controller or device malfunction. Reset the system and retry the command.

**error 064B: \_\_\_: Device not ready**

This type of error occurs when the device is off-line, disk is not up to speed, or malfunctioning. Ensure that the device is off-line and operational. Reset the system and retry command.

**error 064C: \_\_\_: Unit attention condition**

This type of error occurs for an unexpected SCSI device/bus reset, device power loss, or media change. Ensure that the device is on-line and operational. Reset the system and retry command.

**error 064D: \_\_\_: Device hit a filemark**

This type of error occurs for an unexpected filemark or the End-Of-Valid-Data indicator was hit during tape operations. Probable tape read error. Reset the system and retry the command. If subsequent attempts also fail, secure a new tape and retry command. If, with a new tape, the attempt fails, suspect the device is malfunctioning and should be replaced.

**error 064E: \_\_\_: Device reports end-of-medium**

This type of error occurs for an unexpected filemark or the End-Of-Valid-Data indicator was hit during tape operations. Probable tape read error. Reset the system and retry the command. If subsequent attempts also fail, secure a new tape and retry command. If, with a new tape, the attempt fails, suspect the device is malfunctioning and should be replaced.

**error 064F: \_\_\_: Device busy**

This error occurs when an unexpected "BUSY" condition is reported by the SCSI device. Reset the system and retry the command. If the error condition still exists, suspect a device malfunction and replace suspected device.

### 650 Series Console Errors

These error codes (0650 through 065A) apply to the SCSI Adapter and the definition of the symptom will reflect which controller is displaying the error code. For example, if **error 0650: Bad NCR module id** is displayed on the console terminal then the NCR controller is the source of the error code.

**error 0650: Bad \_\_\_ module id**

A probe for a controller returned a bad module id code. Ensure that a controller exists in the slot being probed. If a controller exists suspect the controller.

**error 0651: Bad \_\_\_ bus no**

An open of a device was attempted with a bad bus number. Ensure that a valid bus number (0 = primary) is specified on the **fd** command.

**error 0652: Bad \_\_\_ slot no**

An open of a device was attempted with a bad slot number. Ensure that a valid slot number (2 through 9) is specified on the **fd** command.

**error 0653: Bad \_\_\_ ctrl no**

An open of a device was attempted with a bad controller number. Ensure that a valid controller number (2 through 9) is specified on the **fd** command.

**error 0654: Bad \_\_\_ unit no**

An open of a device was attempted with a bad drive number. Ensure that a valid unit number (0 through 7) is specified on the **fd** command.

**error 0655: Bad \_\_\_ partition no**

An open of a device was attempted with a bad partition number. Ensure that a valid partition number (0 through 7) is specified on the **fd** command.

**error 0657: \_\_\_: SCSI request sense failed**

This type of error occurs when a NCR or SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device or controller malfunction. Attempt to run the I/O diagnostic programs.

**error 0658: \_\_\_: SCSI inquiry failed**

This type of error occurs when a NCR or SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device or controller malfunction. Attempt to run the I/O diagnostic programs.

**error 0659: \_\_\_: SCSI test unit ready failed**

This type of error occurs when a NCR or SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device or controller malfunction. Attempt to run the I/O diagnostic programs.

**error 065A: \_\_\_: SCSI load tape command failed**

This type of error occurs when a NCR or SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device or controller malfunction. Attempt to run the I/O diagnostic programs.

**6B0 Series Console Errors**

These error codes (06B0 through 06B4) apply to the Generic Disk (GD) and Generic Tape (GT) devices, and the definition of the symptom will reflect which controller is displaying the error code. For example, if **error 06B0:GT:Interface not found** is displayed on the console terminal, the generic tape controller is the source of the error code. However, if the generic disk controller is indicating this same error: **error 06B0:GD:Interface not found** is displayed on the console terminal.

**error 06B0: \_\_\_: Interface not found**

This error can only result from an internal hardware or software error.

**error 06B1: \_\_\_: Device not initialized**

This error can only result from an internal hardware or software error.

**error 06B2: \_\_\_: Read failed**

This error results when a I/O controller or device malfunctions, or an internal software error occurs. Suspect the I/O controller or device malfunction. Reset the system and retry the command. If the operation still fails, ensure that the I/O controller and device are all the current revision and run the diagnostic programs to validate the hardware.

**error 06B3: \_\_\_: Write unsupported**

This error can only result from an internal hardware or software error.

**error 06B4: \_\_\_: Bad request size**

This error can only result from an internal hardware or software error.

**error 06C0: GD: Can't read disk status**

This error results when a I/O controller or device malfunctions, or an internal software error occurs. Suspect the I/O controller or device malfunction. Reset the system and retry the command. If the operation still fails, ensure that the I/O controller or device are all the current revision and run the diagnostic programs to validate the hardware.

**error 06C2: GD: Drive off-line**

An I/O request to the GD controller returned drive off-line status. Ensure that the drive is on-line and retry the command.

**error 06C3: GD: Can't read geometry block**

Either an I/O error occurred or the disk has not been formatted. Verify that the disk has been properly formatted. Suspect a medium fault. Restore file and reformat.

**error 06C4: GD: Bad geometry block header**

Either an I/O error occurred or the disk has not been formatted. Verify that the disk has been properly formatted. Suspect a medium fault. Restore file and reformat.

**error 06C5: GD: Bad geometry block checksum**

Either an I/O error occurred or the disk has not been formatted. Verify that the disk has been properly formatted. Suspect a medium fault. Restore file and reformat.

**error 06C6: GD: Null partition**

A null length partition was specified on the **fd** command. To correct this situation, select a different partition with the **fd disk(n,n,partition no.)** command and retry the command. Suspect media.

**error 06D0: GT: Seek failed**

This type of error occurs when a SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device malfunction. Attempt to run the I/O diagnostic programs and replace board(s) indicated.

**error 06D1: GT: Load command failed**

This type of error occurs when a SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device malfunction. Attempt to run the I/O diagnostic programs and replace board(s) indicated.

**error 06D2: GT: Unload command failed**

This type of error occurs when a SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device malfunction. Attempt to run the I/O diagnostic programs and replace board(s) indicated.

**error 06D3: GT: Rewind command failed**

This type of error occurs when a SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device malfunction. Attempt to run the I/O diagnostic programs and replace board(s) indicated.

**error 06D4: GT: Space fwd file command failed**

This type of error occurs when a SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device malfunction. Attempt to run the I/O diagnostic programs and replace board(s) indicated.

**error 06D5: GT: Space back rec command failed**

This type of error occurs when a SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device malfunction. Attempt to run the I/O diagnostic programs and replace board(s) indicated.

**error 06D6: GT: Space fwd rec command failed**

This type of error occurs when a SCSI device is malfunctioning. Reset the system and retry the command. If the error still occurs, suspect a device malfunction. Attempt to run the I/O diagnostic programs and replace board(s) indicated.

**error 06D7: GT: Cannot seek to partition**

This type of error occurs for an unexpected filemark or the End-Of-Valid-Data indicator was hit during tape operations. Probable tape read error. Reset the system and retry the command. If subsequent attempts also fail, secure a new tape and retry command. If, with a new tape, the attempt fails, suspect the device is malfunctioning and should be replaced.

**error 0972: CPU n failed interrupt reset: RHAC = X**

Processor *n* could not reset all interrupt requests.

**error 0973: CPU n IGA configuration ram xxx: expected xx received xx**

Processor *n* interrupt configuration RAM failed test.

**error 0974: CPU n IGA level decode programming failed**

Processor *n* failed the level decode programming.

**error 0975: CPU n IGA ipl decode programming failed**

Processor *n* failed the ipl decode programming.

**error 0976: CPU n IGA vector table programming failed**

Processor *n* failed the vector table programming.

**error 0980: CPU n exception: vector x ("description") epcr x epcip x  
enip x**

Processor *n* had an unexpected exception, a register dump follows to aid in debugging

**error 0981: CPU n cannot be disabled**

Processor *n* can not be disabled via normal procedures.

**error 0983: Cannot single-step across a trap/rte instruction, pc = x**

A trap or rte instruction at pc location *x* cannot be single-stepped.

**0984: exception x occurred while processing exception y**

Another exception *x* occurred during the processing of exception *y*.

**error 0990: board in slot n failed to report board configuration**

The processor board in slot *n* did not power up/reset correctly.

**error 0991: CPU n failed to report status after reset**

Processor *n* did not report its error status after a reset.

**error 0992: CPU n reported error code x (description)**

Processor *n* reported error *x* which is described here.

**error 0993: Global memory x failed RAM test**

The global memory *x* failed RAM test during reset, and is currently not being used by the console.

**error 0999: Backplane reset aborted**

An error condition was detected which caused the reset of the backplane to be aborted.

## Numerics

640 Series error codes B-7  
650 Series Error Codes B-8  
6B0 Series Error Codes B-9

## A

Address Value 3-6  
Alphabetical List of Commands A-1

## C

Command Editing 3-9  
Command Format 3-4  
    Command Manipulators 3-7  
Command Manipulators 3-7  
Command Parameter Definitions A-9  
Command Specifier 3-5  
Console Commands 3-10  
    ASCII DUMP 3-11  
    BOOT OPERATING SYSTEM 3-25  
    CLEAR BREAKPOINTS 3-16  
    CONFIGURE CPU DOWN 3-57  
    CONFIGURE CPU UP 3-59  
    CONFIGURE MASTER CPU 3-58  
    COPY MEMORY 3-17  
    DISASSEMBLE MEMORY 3-22  
    DISPLAY DIRECTORY 3-27  
    DISPLAY MEMORY IN HEXADECIMAL 3-19  
    DISPLAY MOUNTED FILE SYSTEMS 3-30  
    DISPLAY SPECIAL PURPOSE REGISTERS  
        3-45  
    EXAMINE/CHANGE MEMORY 3-23  
    EXECUTE RUN 3-49  
    EXECUTE RUN TO ADDRESS 3-50  
    GENERAL REGISTER DISPLAY/MODIFY 3-33  
    GLOBAL COMMAND OPTIONS 3-39  
    HELP COMMAND 3-63  
    INITIALIZE 3-61

INITIALIZE MEMORY TO VALUE (FILL) 3-35,  
    3-36  
KICK CPUs 3-37  
LIST BREAKPOINTS 3-14  
LOAD A PROGRAM 3-31  
LOAD AND EXECUTE A PROGRAM 3-32  
MEMORY TEST 3-38  
PROCESSOR REGISTER DISPLAY/MODIFY  
    3-40, 3-41  
QUERY ADDRESS 3-43  
QUERY BACKPLANE 3-44  
QUERY BOOT OPTIONS 3-48  
QUERY STACK 3-46  
QUERY VIRTUAL ADDRESS 3-47  
RUN TO NEXT INSTRUCTION 3-52  
RUN TO RETURN ADDRESS 3-53  
RUN WITHOUT BREAKPOINTS 3-51  
SEARCH MEMORY FOR DATA 3-54  
SEARCH MEMORY RANGE FOR DATA 3-56  
SET BREAKPOINTS 3-15  
SINGLE-STEP PROCESSOR 3-62  
WRITE DATA TO MEMORY 3-60  
Console Debugger Error Codes B-4  
Console Debugging Commands--Summary 3-3  
Console Initialization 2-4  
Console Special Key Functions 3-9  
Console Terminal Selection 1-1

## D

Data Size and Formats 3-5  
Debugger Error Codes B-1  
display/set the default device 3-28

## E

Execution Commands A-7

**F**

FDiag Initialization 2-1  
File Operations Commands A-6

**G**

Global Options 3-5

**H**

Help Command A-8

**I**

I/O Error Codes B-5

**L**

Local Options 3-6

**M**

Miscellaneous Commands A-8

**N**

Numeric Values 3-6

**P**

PPCBUG routine 1-1  
program counter 3-49

**R**

Register and Memory Manipulation Commands A-5

**S**

SMON Initialization 2-2  
Summary of Commands 3-1  
    Command Editing 3-9  
Syntax Conventions 3-2  
System Boot 2-5  
System Entry to Console 2-7  
System Initialization 2-1

**V**

VGM5 Reset Switch 2-8  
VGM5 SMI Switch 2-8  
VSS4 Reset Switch 2-9  
VSS4 SMI Switch 2-9







**Spine for 1/2" Binder**

**Product Name: 0.5" from  
top of spine, Helvetica,  
36 pt, Bold**

**Volume Number (if any):  
Helvetica, 24 pt, Bold**

**Volume Name (if any):  
Helvetica, 18 pt, Bold**

**Manual Title(s):  
Helvetica, 10 pt, Bold,  
centered vertically  
within space above bar,  
double space between  
each title**

**Bar: 1" x 1/8" beginning  
1/4" in from either side**

**Part Number: Helvetica,  
6 pt, centered, 1/8" up**

**Power Hawk  
Series 700 Systems**

**Hardware**

**Power  
Hawk  
Series 700  
Console  
Ref Man**

0830059

